



ERP

A Part Of
Something
Better[®]



TABLE OF CONTENTS

COOKING

Appliance Bulbs.....	2
Bake and Broil Elements.....	2-6
BBQ Igniters	9
Burners.....	6-7
Burner Caps	7
Burner Valve.....	7
Door Handles.....	7
Drip Pans	7-9
Filters.....	9
Grates.....	9
Igniters	9-11
Infinite Switches.....	11-14
Knobs.....	14-17
Knob Kits	17-18
Motors	18
Oven Control Boards	18-19
Oven Door Gaskets.....	19-20
Oven Pilots	20
Oven Racks	20-21
Oven Sensors.....	21-22
Paints.....	22
Pressure Regulators.....	22
Safety Valves.....	22-23
Spark Modules	23-24
Surface Elements.....	25-29
Terminal Blocks.....	29
Thermal Fuses	29-30
Thermostats.....	30-31

DISHWASHER

Detergent Dispensers.....	32
Door Springs	33
Gaskets.....	33-34
Pumps.....	35-37
Rollers	37-38
Spray Arms.....	38
Thermal Fuses	39
Thermostat.....	39
Water Valves.....	39-40

DRYER

Belts.....	41-42
Blower Wheels.....	42
Coil Kits.....	42
Door Switches	42-43
Drum Bearings.....	43
Drum Glides	43
Elements.....	44-45
Felts	45
Idler Pulleys	46-47
Igniters.....	47
Knobs.....	48
Lint Filter/Screens	48-50
Motor.....	50
Rollers	51

Thermal Fuses	52-53
Thermistors	53
Thermostats.....	53-55
Timers.....	55

HVAC

Flame Sensors	56
Furnace Igniters.....	56-57
Ignition Modules.....	57
Motors	57-58
Super Seal.....	58

MICROWAVE

Bulbs	59
Capacitors.....	59
Fuses/Diodes.....	59-60
Door Handles.....	60
Magnetrons	60-62
Switches.....	62
Turntable Trays	63

REFRIGERATION

Bin	64
Capacitors.....	64
Cold Controls	64-65
Defrost Heaters	66-67
Defrost Thermostats	67-68
Defrost Timers.....	69-70
Door Bars	70
Door Gaskets	70-73
Handles	75
Ice Makers.....	75-76
Motors	76-82
Overloads/Relays.....	82-83
Spun Copper Driers.....	83
Temperature Sensors.....	84-85
Thermistors.....	85
Water Filters	86
Water Valves.....	86-90

WASHER

Actuators.....	91
Belts.....	92-93
Couplers	93
Door Boots	94
Hoses	95
Knobs.....	95-96
Latches	96
Lid Switches	96-97
Locks	97-98
Pressure Switches	98-99
Pumps.....	99-102
Shock Absorbers.....	103-104
Suspension Rods/Kits.....	104-105
Timers.....	105
Water Valves.....	106-110



Part No. **WB2X7909**
Anti-Tip Kit
 51-1/2" chain length
 Replacement for GE



Part No. **10C7**
Appliance Bulb
 130V, 10 watt
 Candelabra base




Part No. **40A15**
Appliance Bulb
 120V, 40 watt
 Medium base




Part No. **40T61/2**
Appliance Bulb
 120V, 40 watts
 Intermediate base


Measurement Key for Elements



A = Measurement between terminals
 B = Measurement between terminal end & mounting bracket
 C = Measurement between mounting bracket and end of element
 D = Measurement of element width




Part No. **B775**
Bake Element
 Watts: 2400/1800 Volts: 240/208
 Has .250" male terminal push-in connection




A = 1-3/4"
 B = 3-1/4"
 C = 14-3/4"
 D = 19-3/4"

Part No. **B777**
Bake Element
 Watts: 2750/2065 Volts: 240/208
 Has .250" male terminal push-in connection




A = 12-1/8"
 B = 3"
 C = 15"
 D = 15-3/4"

Part No. **B778**
Bake Element
 Watts: 2100/1577 Volts: 240/208
 Has .250" male terminal push-in connection




A = 1-3/4"
 B = 3"
 C = 15-3/4"
 D = 16-5/8"

Part No. **B790**
Bake Element
 Watts: 2600/1950 Volts: 240/208
 Has .250" male terminal push-in connection




A = 14"
 B = 3-1/4"
 C = 15-5/8"
 D = 19-1/8"

Part No. **B837**
Bake Element
 Watts: 2400 Volts: 240
 Has .250" male terminal push-in connection




A = 1-3/4"
 B = 2"
 C = 16"
 D = 16"

Part No. **B856**
Bake Element
 Watts: 2750/2065 Volts: 240/208
 Has .250" male terminal push-in connection



A = 19"
 B = 3-1/4"
 C = 15-1/4"
 D = 19"


Part No. **B0750**
Bake Element
 Watts: 2585/1939 Volts: 240/208
 Has .250" male terminal push-in connection



A = 2"
B = 3"
C = 13-3/8"
D = 15-1/8"

Part No. **B1094**
Bake Element


Watts: 2500 Volts: 240
Has .250" male terminal push-in connection



A = 2"
B = 3-5/8"
C = 15"
D = 18-1/4"

Part No. **B1117**
Bake Element


Watts: 3600 Volts: 240
Has .250" male terminal push-in connection



A = 12-5/8"
B = 4"
C = 15-3/4"
D = 17-3/8"

Part No. **B2200**
Bake Element


Watts: 3500 Volts: 240
Has .250" male terminal push-in connection



A = 13-1/2"
B = 2-3/8"
C = 14-7/8"
D = 13-1/2"

Part No. **B2395**
Bake Element


Watts: 2000 Volts: 250
Has .250" male terminal push-in connection



A = 14"
B = 3"
C = 15-3/4"
D = 14-1/4"

Part No. **B3800**
Bake Element


Watts: 3500 Volts: 240
Has .250" male terminal push-in connection



A = 2"
B = 3-1/4"
C = 15-3/8"
D = 18-7/8"

Part No. **B4107**
Bake Element


Watts: 2585/1939 Volts: 240/208
Has .250" male terminal push-in connection



A = 2-1/4"
B = 4"
C = 15-1/2"
D = 20-1/8"

Part No. **B5002**
Bake Element


Watts: 3000 Volts: 240
Has .250" male terminal push-in connection



A = 16-1/8"
B = 3-3/8"
C = 14-3/4"
D = 19-1/4"

Part No. **B5103**
Bake Element


Watts: 2600 Volts: 240
Has .250" male terminal push-in connection



A = 13"
B = 3-1/2"
C = 15-7/8"
D = 15-5/8"

Part No. **B5900**
Bake Element


Watts: 3500 Volts: 240
Has .250" male terminal push-in connection



A = 19-1/2"
B = 3-1/2"
C = 15-1/4"
D = 19-1/2"

Part No. **B7019**
Bake Element


Watts: 2800/2100 Volts: 240/208
Has .250" male terminal push-in connection



A = 21-1/2"
B = 2-1/4"
C = 16-1/4"
D = 21-1/2"

Part No. **B7646**
Bake Element

Watts: 2600 Volts: 240
Has .250" male terminal push-in connection




A = 2-1/8"
B = 2-1/2"
C = 15-1/4"
D = 20-3/8"


Part No. **B8541**
Bake Element

Watts: 2400/1800 Volts: 240/208
Has .250" male terminal push-in connection

Measurement Key for Elements



- A = Measurement between terminals
- B = Measurement between terminal end & mounting bracket
- C = Measurement between mounting bracket and end of element
- D = Measurement of element width




- A = 21"
- B = 1-7/8"
- C = 17-3/4"
- D = 21"

Part No. **DG47-00038B**

Bake Element

Watts: 2400 Volts: 240
Has .250" male terminal push-in connection




- A = 2-1/2"
- B = 2-1/2"
- C = 16-1/2"
- D = 20"

Part No. **MEE36593202**

Bake Element

Watts: 3400 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-1/2"
- C = 16-1/2"
- D = 14"

Part No. **MEE62306504**

Bake Element

Watts: 4200 Volts: 240
Has .250" male terminal push-in connection




- A = 2"
- B = 1-3/8"
- C = 15-1/4"
- D = 14-5/8"

Part No. **W10207397**

Bake Element

Watts: 2000 Volts: 240
Has .250" male terminal push-in connection




- A = 2"
- B = 3-1/2"
- C = 16-1/2"
- D = 20-1/2"

Part No. **W10779716**

Bake Element

Watts: 3800 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 4"
- C = 16"
- D = 17"

Part No. **WB44K5012**

Bake Element

Watts: 2850 Volts: 240
Has .250" male terminal push-in connection




- A = 1-3/4"
- B = 3"
- C = 16"
- D = 13-3/4"

Part No. **WB44K5013**

Bake Element

Watts: 2000 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-1/2"
- C = 15-1/4"
- D = 17-3/4"

Part No. **WB44K10005**

Bake Element

Watts: 2585 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-3/4"
- C = 17"
- D = 18"

Part No. **WB44T10010**

Bake Element

Watts: 2585 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-1/4"
- C = 16-7/8"
- D = 17-3/4"

Part No. **WB44T10011**

Bake Element

Watts: 3410 Volts: 240
Has .250" male terminal push-in connection




- A = 3"
- B = 2-5/8"
- C = 16-3/8"
- D = 18-7/8"

Part No. **WB44T10014**

Bake Element


Watts: 3800 Volts: 240
Has .250" male terminal push-in connection



A = 1-7/8"
B = 2-3/4"
C = 22-1/2"
D = 16-3/4"

Part No. **WB44T10104**
Bake Element


Watts: 2850 Volts: 240
Has .250" male terminal push-in connection



A = 1-1/4"
B = 2-1/2"
C = 16-1/4"
D = 13-3/8"

Part No. **WB44X200**
Bake Element


Watts: 3100/2330 Volts: 250/208
Has screw-in connection



A = 1-1/4"
B = 1-3/8"
C = 15"
D = 13-1/4"

Part No. **WB44X5043**
Bake Element


Watts: 3000 Volts: 250
Has screw-in connection



A = 1-1/4"
B = 2-1/2"
C = 14-3/4"
D = 17-5/8"

Part No. **WB44X5082**
Bake Element


Watts: 2585/1940 Volts: 250/208
Has screw-in connection



A = 1-1/4"
B = 1-1/2"
C = 16"
D = 17-3/4"

Part No. **WB44X5099**
Bake Element


Watts: 2585/1940 Volts: 250/208
Has screw-in connection



A = 1-3/4"
B = 3-1/4"
C = 15-1/2"
D = 18"

Part No. **WB44X10009**
Bake Element


Watts: 2585/1940 Volts: 240/208
Has .250" male terminal push-in connection



A = 1-1/2"
B = 3"
C = 15-1/2"
D = 18-5/8"

Part No. **WB44X10016**
Bake Element


Watts: 3410 Volts: 240
Has .250" male terminal push-in connection



A = 12"
C = 18-7/8"
D = 11-3/4"

Part No. **B779**
Broil Element


Watts: 3000/2250 Volts: 240/208
Has .250" male terminal push-in connection



A = 13"
B = 3-1/2"
C = 14-7/8"
D = 13"

Part No. **B1551**
Broil Element


Watts: 2100 Volts: 240
Has .250" male terminal push-in connection



A = 11-3/4"
B = 3-1/4"
C = 15-3/8"
D = 11-3/4"

Part No. **B3200**
Broil Element


Watts: 3000 Volts: 240
Has .250" male terminal push-in connection



A = 12-3/8"
B = 3-1/4"
C = 15-3/8"
D = 12-3/8"

Part No. **B3301**
Broil Element

Watts: 4000 Volts: 240
Has .250" male terminal push-in connection




A = 9"
B = 2-5/8"
C = 16-3/4"
D = 18-7/8"


Part No. **B7340**
Broil Element

Watts: 3400/2550 Volts: 240/208
Has .250" male terminal push-in connection

Measurement Key for Elements



- A = Measurement between terminals
- B = Measurement between terminal end & mounting bracket
- C = Measurement between mounting bracket and end of element
- D = Measurement of element width




- A = 1-1/2"
- B = 2-5/8"
- C = 15-5/8"
- D = 13-3/4"

Part No. **WB44K5009**

Broil Element

Watts: 3400 Volts: 240
Has .250" male terminal push-in connection




- A = 1-3/4"
- B = 2-11/16"
- C = 16-7/8"
- D = 14"

Part No. **WB44K10002**

Broil Element

Watts: 3410 Volts: 240
Has .250" male terminal push-in connection




- A = 1-1/4"
- B = 1-3/8"
- C = 15-1/2"
- D = 11-3/4"

Part No. **WB44X173**

Broil Element

Watts: 3400 Volts: 240
Has screw-in connection



- A = 1-1/2"
- B = 2-1/2"
- C = 17"
- D = 11-3/4"

Part No. **WB44T10009**

Broil Element

Watts: 3410 Volts: 240
Has .250" male terminal push-in connection



Part No. **3412A004-19**

Burner (Double)

Replacement for Whirlpool



Part No. **WB16K10026**

Burner (Double)

3" height • 11-5/8" length
Replacement for GE



Part No. **1398**

Burner (Front)

3-7/8" height • 8-1/8" length
Replacement for Peerless



Part No. **1801M58**

Burner (Front)

2-3/4" height • 9-3/8" length
Replacement for Brown



Part No. **316039002**

Burner (Front)


3-1/8" height • 7-5/8" length
Replacement for Electrolux



Part No. **316103802**

Burner (Front)

3-1/8" height • 7-5/8" length
Replacement for Electrolux



Part No. **1801M59**

Burner (Rear)

4-1/2" height • 15-3/8" length
Replacement for Brown



Part No. **316039003**
Burner (Rear)
 3-5/8" height • 13-3/4" length
 Replacement for Electrolux



Part No. **DG62-00074C**
Burner
 1" height • 3-3/4" length
 Replacement for Samsung



Part No. **DG62-00076B**
Burner
 1" height • 1-3/4" length
 Replacement for Samsung



Part No. **DG62-00067A**
Burner Cap (Large)
 3-3/4" diameter
 Replacement for Samsung



Part No. **DG62-00070A**
Burner Cap (Medium)
 2-5/8" diameter
 Replacement for Samsung



Part No. **DG62-00111A**
Burner Cap (Small)
 1-5/8" diameter
 Replacement for Samsung



Part No. **W10169985**
Burner Cap
 2-3/8" diameter
 Replacement for Whirlpool



Part No. **W10183368**
Burner Cap
 3-3/4" diameter
 Replacement for Whirlpool



Part No. **W10141709**
Burner Valve
 270° shaft rotation, saddle mount
 Replacement for Whirlpool



Part No. **316270200**
Door Handle
 29" length x 1-3/8" wide
 Replacement for Electrolux



Part No. **316270201**
Door Handle
 29" length x 1-3/8" wide
 Replacement for Electrolux



Part No. **DB6GE1**
Drip Pan (6")



Part No. **DB6GE2**
Drip Pan (6")



Part No. **DB6WH**
Drip Pan (6")



Part No. **DBU6**
Drip Pan (6")



Part No. **DBU6P**
Drip Pan (6")



Part No. **DBU6P1**
Drip Pan (6")



Part No. **DB8GE1**
Drip Pan (8")



Part No. **DB8GE2**
Drip Pan (8")



Part No. **DB8WH**
Drip Pan (8")



Part No. **DBU8**
Drip Pan (8")



Part No. **DBU8P**
Drip Pan (8")



Part No. **DBU8P1**
Drip Pan (8")



Part No. **TR6GE**
Trim Ring (6")



Part No. **TR8GE**
Trim Ring (8")



Part No. **8504**
Filter (Aluminum Grease)
8-3/4" x 10-1/2", 3/32" thick



Part No. **FLTR012**
Filter (Aluminum Grease)
5-1/8" x 7-5/8", 3/32" thick



Part No. **WB06X10596**
Filter (Aluminum Grease)
5-7/8" x 13-3/8", 3/32" thick




Part No. **WB6X486**
Filter (Aluminum Grease)
7-3/4" x 9", 3/32" thick



Part No. **WB02X10700**
Filter (Combination)
9" x 10-1/2", 3/32" thick



Part No. **WB31K10012**
Grate
8-1/2" x 8-1/2", 1-1/4" height
Replacement for GE



Part No. **WB31X20643**
Grate
8-1/2" x 8-3/4", 2" height
Replacement for GE




Part No. **NEX200828**
Igniter (BBQ)
6 outlet
Used on Jenn-Air



Part No. **644424**
Igniter (Oven)
8-1/2" lead wires
1-1/2" ceramic block




Part No. **316489403**
Igniter (Oven)
15-1/2" lead wires




Part No. **DG94-00520A**
Igniter (Oven)
1-1/2" ceramic block







Part No. **DG94-01012A**
Igniter (Oven)
 One 8" & one 9-1/2" lead wires
 1-1/2" ceramic block



Part No. **GR403**
Igniter (Oven)
 12" lead wires




Part No. **IG0001**
Igniter (Oven)
 12" lead wires
 1-1/2" ceramic block



Part No. **IG21**
Igniter (Oven)
 8" lead wires
 1-1/2" ceramic block




Part No. **IG35**
Igniter (Oven)
 8" lead wires
 1-1/2" ceramic block




Part No. **IG5652**
Igniter (Oven)
 10" lead wires
 1-1/2" ceramic block




Part No. **IG9400**
Igniter (Oven)
 16" lead wires
 1-1/2" ceramic block




Part No. **IG9998**
Igniter (Oven)
 17" lead wires
 1-1/2" ceramic block



Part No. **IG10016**
Igniter (Oven)
 15", 12" & 8" lead wires
 1-1/2" ceramic block



Part No. **MEE61841401**
Igniter (Oven)
 11" lead wires
 1-1/2" ceramic block



Part No. **WB13K10043**
Igniter (Oven)
 17-3/4" lead wires
 1-3/8" ceramic block



Part No. **189324**
Igniter (Spark)
 Has .110" male terminal
 Replacement for Bosch





Part No. **74005890**
Igniter (Spark)
 Replacement for Whirlpool



Part No. **8523793**
Igniter (Spark)
 Has .25" male terminal
 Replacement for Whirlpool




Part No. **9758079**
Igniter (Spark)
 Has .110" male terminal
 Replacement for Whirlpool



Part No. **W10209656**
Igniter (Spark)
 29-1/2" lead wire with .110" female end
 Replacement for Whirlpool



Part No. **W10209656KIT**
Igniter (Spark)
 29-1/2" lead wire with .110" female end
 Replacement for Whirlpool



Part No. **W10324262**
Igniter (Spark)
 Has .110" male terminal
 Replacement for Whirlpool



Part No. **W10333842**
Igniter (Spark)
 Has .110" male terminal
 Replacement for Whirlpool



Part No. **W10515459**
Igniter (Spark)
 Has .25" male terminal
 Replacement for Whirlpool



Part No. **W10278150**
Igniter Clip



Part No. **3148952**
Infinite Switch
 Current sensing type
 240V, 5.4 - 7.8 amp
 Replacement for Whirlpool




Part No. **3148953**
Infinite Switch
 Current sensing type
 240V, 7.5 - 9.3 amp
 Replacement for Whirlpool



Part No. **3149400**
Infinite Switch
 Current sensing type
 240V, 8.9 - 11 amp
 Replacement for Whirlpool



Part No. **3149404**
Infinite Switch
 Current sensing type
 240V, 5.2 - 6.6 amp
 Replacement for Whirlpool



Part No. **5500200**
Infinite Switch
 Voltage sensing type, 240V, 13 amp
 Includes square breakoff shaft with multiple nylon adapter inserts for virtually all knobs used by Electrolux, GE, Maytag, Whirlpool & others



Part No. **5500202M**
Infinite Switch
 Voltage sensing type, 240V, 13 amp
 Includes square breakoff shaft with multiple nylon adapter inserts for virtually all knobs used by Electrolux, GE, Maytag, Whirlpool & others



Part No. **5502404**
Infinite Switch
 Voltage sensing type
 240V, 15 amp



Part No. **316238201**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for Electrolux



Part No. **316238202**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for Electrolux




Part No. **316436000**
Infinite Switch
 Current sensing type
 240V, 5.2 - 6.25 amp
 Replacement for Electrolux



Part No. **316436001**
Infinite Switch
 Current sensing type
 240V, 8.8 - 10.8 amp
 Replacement for Electrolux



Part No. **7403P23960**
Infinite Switch
 Current sensing type
 240V, 8.9 - 11 amp
 Replacement for Whirlpool



Part No. **807004702**
Infinite Switch
 240V
 Replacement for Whirlpool



Part No. **DG44-01002A**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for Samsung



Part No. **DG44-01008A**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for Samsung



Part No. **DG44-01009A**
Infinite Switch
 Current sensing type
 240V, 4.4 - 5.8 amp
 Replacement for Samsung



Part No. **W10434452**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for Whirlpool



Part No. **W10857622**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for Whirlpool



Part No. **WB23K5027**
Infinite Switch
 Current sensing type
 240V, 8.9 - 11 amp
 Replacement for GE



Part No. **WB23K10003**
Infinite Switch
 Current sensing type
 240V, 8.9 - 11 amp
 Replacement for GE



Part No. **WB23M24**
Infinite Switch
 Current sensing type
 240V, 5.2 - 6.6 amp
 Replacement for GE



Part No. **WB24T10022**
Infinite Switch
 Current sensing type
 240V, 4.4 - 5.8 amp
 Replacement for GE



Part No. **WB24T10025**
Infinite Switch
 Current sensing type
 240V, 8.9 - 11 amp
 Replacement for GE



Part No. **WB24T10027**
Infinite Switch
 Current sensing type
 240V, 7.5 - 9.3 amp
 Replacement for GE



Part No. **WB24T10029**
Infinite Switch
 Current sensing type
 240V, 4.4 - 7.4 amp
 Replacement for GE



Part No. **WB24T10058**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for GE



Part No. **WB24T10063**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for GE



Part No. **WB24T10119**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for GE



Part No. **WB24T10134**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for GE



Part No. **WB24T10146**
Infinite Switch
 Current sensing type
 240V, 7.2 - 9.0 amp
 Replacement for GE



Part No. **WB24T10153**
Infinite Switch
 Voltage sensing type
 240V, 13 amp
 Replacement for GE



Part No. **WB24T10162**
Infinite Switch
 Voltage sensing type
 240V
 Replacement for GE



Part No. **WB24X25013**
Infinite Switch
 Voltage sensing type
 240V, 15 amp
 Replacement for GE



Part No. **6286W**
Knob (Burner)
 Flush shaft
 Replacement for Peerless Premier

"D" position
 .256



Part No. **7737P245-60**
Knob (Burner)
 1/2" extended shaft
 Replacement for Whirlpool

"D" position
 .256



Part No. **3181304**
Knob (Burner)
 3/4" extended shaft
 Replacement for Whirlpool

"D" position
 .256



Part No. **8273106**
Knob (Burner)
 1/8" extended shaft
 Replacement for Whirlpool

"D" position
 .256



Part No. **71001641**
Knob (Burner)
 5/8" extended shaft
 Replacement for Whirlpool

"D" position
 .340



Part No. **74007733**
Knob (Burner)
 1/4" extended shaft
 Replacement for Whirlpool

"D" position
 .256



Part No. **74010205**
Knob (Burner)
 1/4" extended shaft
 Replacement for Whirlpool

"D" position
 .256



Part No. **74010839**
Knob (Burner)
 1/4" extended shaft
 Replacement for Whirlpool

"D" position
 .256



Part No. **74011260**
Knob (Burner)
 1/2" extended shaft
 Replacement for Whirlpool

"D" position
 .256



Part No. **74011287**
Knob (Burner)
 1/4" extended shaft
 Replacement for Whirlpool

"D" position
 .256



Part No. **316220000**
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

"D" position
 .340



Part No. **316220008**
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

"D" position
 .256



Part No. **316220009**
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

"D" position
 .256



Part No. **316353104**
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

"D" position
 .256



Part No. **316543907**
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

"D" position
 .256



Part No. **316564509**
Knob (Burner)
 3/8" extended shaft
 Replacement for Electrolux

"D" position
 .340



Part No. **318099104**
Knob (Burner)
 1/2" extended shaft
 Replacement for Electrolux

"D" position
 .340



Part No. **5304507386**
Knob (Burner)
 1/2" extended shaft
 Replacement for Electrolux

"D" position
 .340



Part No. **5304509929** "D" position
Knob (Burner)
 1/2" extended shaft
 Replacement for Electrolux



Part No. **W10160375** "D" position
Knob (Burner)
 1/4" extended shaft
 Replacement for Whirlpool



Part No. **W10339442** "D" position
Knob (Burner)
 1/8" extended shaft
 Replacement for Whirlpool



Part No. **W10370189** "D" position
Knob (Burner)
 1/8" extended shaft
 Replacement for Whirlpool



Part No. **W10766544** "D" position
Knob (Burner)
 1/8" extended shaft
 Replacement for Whirlpool



Part No. **W10836470** "D" position
Knob (Burner)
 1/8" extended shaft
 Replacement for Whirlpool



Part No. **W11544663** "D" position
Knob (Burner)
 3/4" extended shaft
 Replacement for Whirlpool



Part No. **WB03K10216** "D" position
Knob (Burner)
 3/8" extended shaft
 Replacement for GE



Part No. **WB03K10265** "D" position
Knob (Burner)
 1-3/8" extended shaft
 Replacement for GE



Part No. **WB03K10303** "D" position
Knob (Burner)
 1/2" extended shaft
 Replacement for GE



Part No. **WB03K10305** "D" position
Knob (Burner)
 1/8" extended shaft
 Replacement for GE



Part No. **WB03T10325** "D" position
Knob (Burner)
 3/8" extended shaft
 Replacement for GE





Part No. **WB3X712**

Knob (Burner)
5/8" extended shaft
Replacement for GE

"D" position



Part No. **Y700854**

Knob (Burner)
Flush shaft
Replacement for Whirlpool

"D" position



Part No. **316102303**

Knob (Thermostat)
Flush shaft
Replacement for Whirlpool

"D" position



Part No. **WB03K10036**

Knob (Thermostat)
1/2" extended shaft
Replacement for GE

"D" position



Part No. **WB03K10159**

Knob (Thermostat)
1/2" extended shaft
Replacement for GE

"D" position



Part No. **WB03K10187**

Knob (Thermostat)
1/8" extended shaft
Replacement for GE

"D" position



Part No. **WB03K10202**

Knob (Thermostat)
Flush shaft
Replacement for GE

"D" position



Part No. **WB03K10302**

Knob (Thermostat)
1/8" extended shaft
Replacement for GE

"D" position



Part No. **KN001**

Knob Kit (Universal Gas)
Kit includes: (5) knobs, (4) burner inlays,
(1) thermostat inlay, (5) black inserts,
(5) white inserts



Part No. **KN002**

Knob Kit (Universal Electric)
Kit includes: (5) knobs, (8) burner inlays,
(2) thermostat inlays, (5) blue inserts,
(5) gray inserts, (5) green inserts,
(5) red inserts, (5) yellow inserts



Part No. **W10698166**

Knob Kit (Burner)
Kit includes: (5) knobs
Replacement for Whirlpool



Part No. **W10762263**

Knob Kit (Burner)
Kit includes: (5) knobs
Replacement for Whirlpool




Part No. **WB03X23020**
Knob Kit (Burner)
 Kit includes: (5) knobs
 Replacement for GE



Part No. **W10490648**
Mixer Beaters (Pair)
 Replacement for Whirlpool



Part No. **EAU61865301**
Motor (Convection)
 Replacement for LG



Part No. **EAU62343001**
Motor (Convection)
 Replacement for LG



Part No. **DG31-00005A**
Motor (Convection)
 Replacement for Samsung



Part No. **W10556710**
Oven Control Board
 Replacement for Whirlpool



Part No. **W11122531**
Oven Control Board
 Replacement for Whirlpool



Part No. **W11122536**
Oven Control Board
 Replacement for Whirlpool



Part No. **W11122543**
Oven Control Board
 Replacement for Whirlpool



Part No. **W11122546**
Oven Control Board
 Replacement for Whirlpool



Part No. **W11122551**
Oven Control Board
 Replacement for Whirlpool



Part No. **W11122555**
Oven Control Board
 Replacement for Whirlpool



Part No. **W11122557**
Oven Control Board
 Replacement for Whirlpool



Part No. **97012038**
Motor (Vent Hood)
 Replacement for Broan



Part No. **97012248**
Motor (Vent Hood)
 Replacement for Broan, GE



Part No. **M550**
Motor (Vent Hood)
 0.55 amps, 3000 RPM
 1-3/4" shaft, CCW Rotation



Part No. **W10380496**
Motor Brush
 Replacement for Whirlpool



Part No. **316239700**
Oven Door Gasket
 50-1/2", 12 mounting clips
 Replacement for Electrolux



Part No. **316405000**
Oven Door Gasket
 84", 16 mounting clips
 Replacement for Electrolux



Part No. **71001841**
Oven Door Gasket
 81", 23 mounting clips
 Replacement for Electrolux



Part No. **7212P043-60**
Oven Door Gasket
 52", 12 mounting clips
 Replacement for Whirlpool



Part No. **W10162384**
Oven Door Gasket
 70-1/2", 25 mounting clips
 Replacement for Whirlpool



Part No. **W10162385**
Oven Door Gasket
 80", 25 mounting clips
 Replacement for Whirlpool



Part No. **W10282960**
Oven Door Gasket
 92", 25 mounting clips
 Replacement for Whirlpool



Part No. **W10658354**
Oven Door Gasket
 71", 20 mounting clips
 Replacement for Whirlpool



Part No. **W10861521**
Oven Door Gasket
 30"
 Replacement for Whirlpool



Part No. **WB2X1522**
Oven Door Gasket
 64-1/4"
 Replacement for GE



Part No. **WB32K3**
Oven Door Gasket
 54", 16 mounting clips
 Replacement for GE




Part No. **74010141**
Oven Pilot
 Standing pilot
 Replacement for Whirlpool



Part No. **WB19K10008**
Oven Pilot
 Standing pilot
 Replacement for GE



Part No. **4334809**
Oven Rack
 22-3/8" wide
 16-1/8" deep
 Replacement for Whirlpool



Part No. **316067902**
Oven Rack
 22-13/16" wide
 16-1/8" deep
 Replacement for Electrolux




Part No. **316496201**
Oven Rack
 24-1/4" wide
 15-7/8" deep
 Replacement for Electrolux



Part No. **W10256908**
Oven Rack
 24" wide
 16" deep
 Replacement for Whirlpool



Part No. **W10282492**
Oven Rack
 22-7/8" wide
 17-1/4" deep
 Replacement for Whirlpool



Part No. **WB48T10011**
Oven Rack
 24-1/8" wide
 18" deep
 Replacement for GE






Part No. **WB48T10063**

Oven Rack

24-1/4" wide
16-7/8" deep
Replacement for GE



Part No. **WB48T10095**

Oven Rack


23-3/4" wide
17-1/2" deep
Replacement for GE



Part No. **WB48X5099**

Oven Rack


22-7/8" wide
16" deep
Replacement for GE



Part No. **00642855**

Oven Sensor

2" long probe
Replacement for Bosch



Part No. **12001655**

Oven Sensor

2" long probe, includes two optional wires
Fits most applications
Replacement for Whirlpool



Part No. **12001656**

Oven Sensor

6" long probe, includes two optional wires
Fits most applications
Replacement for Whirlpool



Part No. **316217002**

Oven Sensor

3-1/4" long probe
Replacement for Electrolux



Part No. **316233902**

Oven Sensor

3-1/4" long probe
Replacement for Electrolux



Part No. **DG32-00002B**

Oven Sensor

2-3/4" long probe
Replacement for Samsung



Part No. **DG32-00004C**

Oven Sensor

Replacement for Samsung



Part No. **W10131825**

Oven Sensor


3" long probe
Replacement for Whirlpool



Part No. **W10181986**

Oven Sensor

6" long probe
Replacement for Whirlpool



Part No. **WB23X5340**
Oven Sensor
 2-1/8" long probe
 Replacement for GE



Part No. **1126**
Paint (Touch Up)
 White



Part No. **1438**
Paint (Touch Up)
 Almond



Part No. **1440**
Paint (Touch Up)
 Bisque



Part No. **1999**
Paint (Touch Up)
 Black



Part No. **316091706**
Pressure Regulator
 1/2" x 1/2" NPT
 4"/10" convertible, Set at 4" natural gas
 Includes shut-off valve
 Replacement for Electrolux




Part No. **PR1**
Pressure Regulator
 1/2" x 1/2" NPT
 4"/10" convertible



Part No. **PR2**
Pressure Regulator
 1/2" x 1/2" NPT
 5"/10" convertible



Part No. **PR4**
Pressure Regulator
 3/4" x 3/4" NPT
 4"/10" convertible



Part No. **DG94-00449A**
Safety Valve & Pressure Regulator Assembly



Part No. **56120**
Safety Valve
 Replacement for Atwood




Part No. **1802A206**
Safety Valve
 3/8" Inlet, includes mounting bracket
 Replacement for Brown




Part No. **3203459**
Safety Valve
 Replacement for Electrolux



Part No. **WB19K31**
Safety Valve
 1/4" female terminals
 Replacement for GE



Part No. **316031501**
Safety Valve
 Replacement for Whirlpool



Part No. **5817S0007**
Safety Valve
 Universal Kit
 Replaces 90% of all 5817 series safety valves



Part No. **6513S0001**
Spark Module
 2+1 (2 manual circuits for top burner ignition & 1 flame sensing circuit for automatic oven re-ignition)
 Has (6) .250" & (3) .110" male terminals



Part No. **6520S0201**
Spark Module
 2+0 (2 manual circuits for top burner ignition & no oven ignition circuit)
 Universal split terminal design suitable for: .110", .187" & .250" push on wiring



Part No. **6540S0001**
Spark Module
 0+4 (No manual circuits for top burner ignition, all 4 top burner circuits are individual flame sensing for automatic top burner re-ignition)
 Has (7) .250" & (4) .110" male terminals



Part No. **6544S0001**
Spark Module
 4+0 (4 manual circuits for top burner ignition & no oven ignition circuit)
 Snap in mounting
 Has (2) .250" & (4) .187" male terminals



Part No. **6545S0001**
Spark Module
 2+0 (2 manual circuits for top burner ignition & no oven ignition circuit)
 Snap in mounting
 Has (2) .250" & (2) .187" male terminals



Part No. **6547S0001**
Spark Module
 4+1 (4 manual circuits for top burner ignition & 1 flame sensing circuit for automatic oven re-ignition)
 Has (6) .250" & (5) .110" male terminals



Part No. **6549S0001**
Spark Module
 2+1 (2 manual circuits for top burner ignition & 1 flame sensing circuit for automatic oven re-ignition)
 Has (6) .250" & (3) .110" male terminals



Part No. **6610341**
Spark Module
 4+0 (4 manual circuits for top burner ignition & no oven ignition circuit)
 Has (2) .250" & (4) .110" male terminals
 Replacement for Whirlpool



Part No. **12001596**

Spark Module


4+0 (4 manual circuits for top burner ignition & no oven ignition circuit)
Has (2) .250" & (4) .110" male terminals
Replacement for Whirlpool



Part No. **808608801**

Spark Module

2+0 (2 manual circuits for top burner ignition & no oven ignition circuit)
Has (1) .250", (1) .187" & (2) .110" male terminals
Replacement for Whirlpool



Part No. **DG96-00297A**

Spark Module


Has (5) .110" and (2) .250" male terminals
Replacement for Samsung



Part No. **PA020047**

Spark Module

0+4 (No manual circuits for top burner ignition, all 4 top burner circuits are individual flame sensing for automatic top burner reignition)
Replacement for Viking



Part No. **W10110486**

Spark Module

Has (3) .250" & (6) .110" male terminals
Replacement for Whirlpool



Part No. **W10110491**

Spark Module

Has (3) .250" & (4) .110" male terminals
Replacement for Whirlpool



Part No. **W10475147**

Spark Module


Has (4) .110" male terminals
Replacement for Whirlpool



Part No. **WB13T10076**

Spark Module


Has (5) .110" male terminals
Replacement for GE



Part No. **W10331686**

Spark Module Circuit Board


This board has diagnostic capabilities to help diagnose problems that may occur in your range. The LED light on your board will blink different codes, whose meanings are printed on the board.
Replacement for Whirlpool



Part No. **W10511278**

Spark Module Circuit Board


Replacement for Whirlpool



Part No. **W10860916**

Spark Module Circuit Board

Replacement for Whirlpool



Part No. **W11162730**

Spark Module Circuit Board

Replacement for Whirlpool



Part No. **WB24T10071**
Spark Switch
 Has a .256" "D" insert
 Replacement for GE



Part No. **S30M1**
Surface Element
 6"- 5 Turn
 1000W@208V 1325W@240V
 Replacement for GE



Part No. **S30M2**
Surface Element
 8"- 6 Turn
 1765W@208V 2350W@240V
 Replacement for GE



Part No. **S36Y12**
Surface Element
 6"- 3 Turn
 1250W@240V



Part No. **S46D15**
Surface Element
 6"- 4 Turn
 1500W@240V



Part No. **S46Y12**
Surface Element
 6"- 4 Turn
 1250W@240V



Part No. **S46Y15**
Surface Element
 6"- 4 Turn
 1500W@240V



Part No. **S48D21**
Surface Element
 8"- 4 Turn
 2100W@240V



Part No. **S48Y21**
Surface Element
 8"- 4 Turn
 2100W@240V



Part No. **S58D21**
Surface Element
 8"- 5 Turn
 2100W@240V



Part No. **S58D26**
Surface Element
 8"- 5 Turn
 2600W@240V



Part No. **S58Y21**
Surface Element
 8"- 5 Turn
 2100W@240V



Part No. **S58Y26**
Surface Element
8" - 5 Turn
2600W@240V



Part No. **S218**
Surface Element
6" - 5 Turn
1000W@208V 1325W@240V
Replacement for GE



Part No. **S219**
Surface Element
8" - 6 Turn
1765W@208V 2350W@240V
Replacement for GE



Part No. **S348**
Surface Element
8" - 6 Turn
1765W@208V 2350W@240V
Replacement for GE



Part No. **S354**
Surface Element
8" - 6 Turn
1600W@208V 2125W@240V
Replacement for GE



Part No. **S359**
Surface Element
6" - 5 Turn
1000W@208V 1325W@240V
Replacement for GE



Part No. **WB30K10002**
Surface Element
6" - 3 Turn
940W@208V 1250W@240V
Replacement for GE



Part No. **WB30K10003**
Surface Element
8" - 4 Turn
1580W@208V 2100W@240V
Replacement for GE



Part No. **WB30T10074**
Surface Element
8" - 5 Turn
1950W@208V 2600W@240V
Replacement for GE



Part No. **WB30T10078**
Surface Element
6" - 4 Turn
1130W@208V 1500W@240V
Replacement for GE



Part No. **530451619**
Surface Element (8" Safety)
2400W@240V
Replacement for Electrolux




Part No. **530451616**
Surface Element (6" Safety)
1500W@240V
Replacement for Electrolux



Part No. **WB30X31057**
Surface Element (8" Safety)
 2400W@240V
 Replacement for GE



Part No. **WB30X31058**
Surface Element (6" Safety)
 1250W@240V
 Replacement for GE



Part No. **8273992**
Surface Element (Radiant Heat)
 10", 2500W@240V
 Replacement for Whirlpool



Part No. **8273993**
Surface Element (Radiant Heat)
 9-3/8", 1800W@240V
 Replacement for Whirlpool




Part No. **316282000**
Surface Element (Radiant Heat)
 9-7/8", 3000W@240V
 Replacement for Electrolux



Part No. **318601604**
Surface Element (Radiant Heat)
 Replacement for Electrolux



Part No. **DG47-00065A**
Surface Element (Radiant Heat)
 11-7/8", 3000W@240V
 Replacement for Samsung



Part No. **DG47-00066A**
Surface Element (Radiant Heat)
 4400/3600/1800W@240V
 Replacement for Samsung



Part No. **DG47-00067A**
Surface Element (Radiant Heat)
 9-7/8", 3300/1400W@240V
 Replacement for Samsung



Part No. **MEE62385201**
Surface Element (Radiant Heat)
 11-3/8", 3200/1400W@240V
 Replacement for LG



Part No. **RS65D12**
Surface Element (Radiant Heat)
 6-1/2", 1200W@240V
 Replacement for Electrolux, Whirlpool



Part No. **RS85D20**
Surface Element (Radiant Heat)
 8-1/2", 2000W@240V
 Replacement for GE, Whirlpool




Part No. **RS975D25**
Surface Element (Radiant Heat)
10", 2500W@240V
Replacement for Electrolux, Whirlpool




Part No. **W10275048**
Surface Element (Radiant Heat)
10", 3000W@240V
Replacement for Whirlpool



Part No. **WB30T10044**
Surface Element (Radiant Heat)
10", 2500W@240V
Replacement for GE



Part No. **WB30T10045**
Surface Element (Radiant Heat)
8-1/2", 2000W@240V
Replacement for GE



Part No. **WB30T10047**
Surface Element (Radiant Heat)
7", 1500W@240V
Replacement for GE



Part No. **WB30T10126**
Surface Element (Radiant Heat)
11-3/4", 3000/1950/1050W@240V
Replacement for GE



Part No. **WB30T10129**
Surface Element (Radiant Heat)
7-1/8", 1500W@240V
Replacement for GE




Part No. **WB30T10130**
Surface Element (Radiant Heat)
11-3/4", 3000/1950W@240V
Replacement for GE




Part No. **WB30T10132**
Surface Element (Radiant Heat)
8-1/2", 2000W@240V
Replacement for GE



Part No. **WB30T10133**
Surface Element (Radiant Heat)
9-3/4", 3100/1300W@240V
Replacement for GE



Part No. **WB30T10135**
Surface Element (Radiant Heat)
10", 1900/800W@240V
Replacement for GE




Part No. **WB30T10136**
Surface Element (Radiant Heat)
9-1/8", 2500W@240V
Replacement for GE



Part No. **WB30T10145**
Surface Element (Radiant Heat)
 6-1/2", 1200W@240V
 Replacement for GE




Part No. **WB30T10155**
Surface Element (Radiant Heat)
 12", 3600/2400/1400W@240V
 Replacement for GE




Part No. **WB30X24111**
Surface Element (Radiant Heat)
 9-3/4", 3100/1300W@240V
 Replacement for GE




Part No. **9755542**
Temperature Probe
 Replacement for Whirlpool



Part No. **12001676**
Terminal Block
 Replacement for Whirlpool



Part No. **330031**
Terminal Block
 Replacement for Whirlpool




Part No. **R117**
Terminal Block
 Universal Replacement



Part No. **WB2X8228**
Terminal Block
 Replacement for GE



Part No. **WB17T10006**
Terminal Block
 Replacement for GE



Part No. **WB17X5113**
Terminal Block
 Replacement for GE



Part No. **8300802**
Thermal Fuse
 Replacement for Whirlpool



Part No. **9759242**
Thermal Fuse
 Cutout @ 130°
 Replacement for Whirlpool




Part No. **9759243**
Thermal Fuse
 Cutout @ 120°
 Replacement for Whirlpool



Part No. **WB19K10025**
Thermocouple
 Replacement for GE




Part No. **6930W1A003X**
Thermostat
 Replacement for LG



Part No. **1842A57**
Thermostat (Electric)
 250V, 22 amp, 7 terminals
 Includes OEM knob
 Replacement for Brown



Part No. **316032411**
Thermostat (Gas/Electric)
 125V, 5 amp, 2 terminals
 Replacement for Electrolux



Part No. **316215900**
Thermostat (Electric)
 250V, 60 Hz, 25 amp, 7 terminals
 Replacement for Electrolux



Part No. **316215901**
Thermostat (Electric)
 250V, 25 amp, 7 terminals
 Replacement for Electrolux




Part No. **3196803**
Thermostat (Electric)
 240V, 25 amp, 3 terminals, Double pole
 Replacement for Whirlpool



Part No. **6700S0011**
Thermostat (Universal Electric)
 240V, 17 amp, 6 terminals
 Replaces most single or double pole thermostats



Part No. **74002390**
Thermostat (Gas/Electric)
 125V, 5 amp, 2 terminals
 Replacement for Whirlpool




Part No. **74005019**
Thermostat (Electric)
 240V, 27 amp, 8 terminals, Double pole
 Replacement for Whirlpool



Part No. **98003984**
Thermostat (Gas/Electric)
 3/4" shaft, 2 terminals, single pole
 120V, 5 amp, 36" capillary
 Replacement for Whirlpool



Part No. **W10159016**
Thermostat (Gas/Electric)
 3/4" shaft, 2 terminals, single pole
 120V, 5 amp, 36" capillary
 Replacement for Whirlpool



Part No. **W10636339**
Thermostat (Electric)
 125V, 5 amp, 2 terminals
 Replacement for Whirlpool



Part No. **WB20K8**
Thermostat (Gas/Electric)
 3/4" shaft, 2 terminals, single pole
 120V, 5 amp, 36" capillary
 Replacement for GE



Part No. **WB20K5027**
Thermostat (Electric)
 250V, 25 amp, 5 terminals
 Replacement for GE



Part No. **WB20K10010**
Thermostat (Electric)
 240V, 20 amp, 6 terminals
 Replacement for GE




Part No. **WB20K10023**
Thermostat (Gas/Electric)
 120V, 20 amp, 2 terminals
 Replacement for GE



Part No. **WB20K10026**
Thermostat (Electric)
 240V, 20 amp, 6 terminals
 Replacement for GE



Part No. **WB20X5071**
Thermostat (Electric)
 240V, 30 amp, 6 terminals
 Replacement for GE



Part No. **WB21X5287**
Thermostat (Electric)
 250V, 25 amp, 5 terminals
 Replacement for GE

DISHWASHER



Part No. **8269145**
Bracket
 Replacement for Whirlpool



Part No. **8268383**
Chopper Assembly
 Replacement for Whirlpool



BACK



Part No. **00645208**
Detergent Dispenser
 Replacement for Bosch



BACK

Part No. **490467**
Detergent Dispenser
 Replacement for Bosch



BACK

Part No. **MCU61861001**
Detergent Dispenser
 Replacement for LG



BACK

Part No. **W10605015**
Detergent Dispenser
 Replacement for Whirlpool



Part No. **DM06N**
Dishwasher Magic
 (Sold in 6PK case ONLY)
 Removes mineral build-up, cleans & disinfects
 Safe for dishwashers, plumbing & septic systems



Part No. **W10508950**
Dishrack Stop (2pk)
 Replacement for Whirlpool



Part No. **154578801**
Door Cable
 Replacement for Electrolux



Part No. **00618605**
Door Cable Kit
 Replacement for Bosch



Part No. **AGM76209501**
Door Latch
 Replacement for LG



Part No. **10006917**
Door Lock
 Replacement for Bosch



Part No. **W10537869**
Diverter Motor
Replacement for Whirlpool



Part No. **154579101**
Door Spring
Replacement for Electrolux



Part No. **8270020**
Door Spring
Replacement for Whirlpool



Part No. **00754866**
Door Spring Kit
Replacement for Bosch



Part No. **00754873**
Door Spring Kit
Replacement for Bosch



Part No. **DD81-02132A**
Door Switch
Replacement for Samsung



Part No. **00668114**
Drain Hose
7/8" ID x 90" length
Replacement for Bosch



Part No. **DWDH78**
Drain Hose
1/2" ID x 78" length
Can be cut and used as extension hose
Universal Replacement



Part No. **154825001**
Element
15-3/4" x 15-3/4" with male spade terminals
Replacement for Electrolux



Part No. **00263096**
Gasket
71" length
Replacement for Bosch



Part No. **00494772**
Gasket
73" length
Replacement for Bosch



Part No. **3920DD3005A**
Gasket
74-3/4" length
Replacement for LG

DISHWASHER



Part No. **902894**
Gasket
76" length
Replacement for Whirlpool



Part No. **154827601**
Gasket
86-1/2" length
Replacement for Electrolux



Part No. **DD62-00043A**
Gasket
73" length
Replacement for Samsung



Part No. **W10300924V**
Gasket
71-1/2" length
Replacement for Whirlpool



Part No. **W10509257**
Gasket
65-1/4" length
Replacement for Whirlpool



Part No. **W10524469**
Gasket
72-7/8" length
Replacement for Whirlpool



Part No. **WD08X10016**
Gasket
88-1/4" length
Replacement for GE



Part No. **WD08X10057**
Gasket
89-1/2" length
Replacement for GE



Part No. **WD8X227**
Gasket (Right Corner)
Replacement for GE




Part No. **WD8X228**
Gasket (Left Corner)
Replacement for GE



Part No. **WD8X229**
Gasket
89" length
Replacement for GE



Part No. **DD31-00013B**
Geared Motor
Replacement for Samsung



Part No. **00480317**
Heater Assembly
Replacement for Bosch



Part No. **W10445975**
Hose Assembly
Replacement for Whirlpool



Part No. **34FHT**
Inlet
90 degree
Replacement for Whirlpool



Part No. **WD21X10261**
Interlock Switch
Replacement for GE



Part No. **8194001**
Link Kit
2 Pack
Replacement for Whirlpool



Part No. **4681ED1004B**
Motor Assembly
Replacement for LG



Part No. **W10879262**
Pump (Circulation)
Replacement for Whirlpool



Part No. **00167082**
Pump (Drain)
Replacement for Bosch



Part No. **00436440**
Pump (Drain)
Replacement for Bosch



Part No. **00611332**
Pump (Drain)
Replacement for Bosch



Part No. **00620774**
Pump (Drain)
Replacement for Bosch



Part No. **00631200**
Pump (Drain)
Replacement for Bosch

DISHWASHER



Part No. **642239**
Pump (Drain)
Replacement for Bosch



Part No. **661658**
Pump (Drain)
Replacement for Whirlpool



Part No. **154580301**
Pump (Drain)
Replacement for Electrolux



Part No. **A00126401**
Pump
Replacement for Electrolux



Part No. **A00126501**
Pump (Drain)
Replacement for Electrolux



Part No. **DD31-00005A**
Pump (Drain)
Replacement for Samsung



Part No. **DD31-00016A**
Pump (Drain)
Replacement for Samsung



Part No. **EAU62043403**
Pump (Drain)
Replacement for LG



Part No. **W10348269**
Pump
Replacement for Whirlpool



Part No. **W10876537**
Pump
Replacement for Whirlpool



Part No. **A00044305**
Pump (Motor)
Replacement for Electrolux



Part No. **W10510667**
Pump (Motor)
Replacement for Whirlpool



Part No. **W10846093**
Pump (Motor)
Replacement for Whirlpool



Part No. **W11412291**
Pump (Motor)
Replacement for Whirlpool



Part No. **W11497943**
Pump (Motor)
Replacement for Whirlpool



Part No. **5304519906**
Pump & Motor Assembly
Replacement for Electrolux



Part No. **W11084656**
Pump & Motor Assembly
Replacement for Whirlpool



Part No. **00611666**
Roller
Replacement for Bosch




Part No. **165314**
Roller
Replacement for Bosch




Part No. **611475**
Roller
Replacement for Bosch



Part No. **12004485**
Roller Kit (8pk)
Replacement for Bosch



Part No. **8268743**
Roller Assembly
Replacement for Whirlpool



Part No. **8561996**
Roller Assembly (Adjustable)
Replacement for Whirlpool



Part No. **W10195416**
Roller Assembly
Replacement for Whirlpool

DISHWASHER



Part No. **W10888592**
Roller Assembly
Replacement for Whirlpool



Part No. **DD82-01121A**
Rack Adjuster
Replacement for Samsung



Part No. **W10546503**
Rack Adjuster
Replacement for Whirlpool



Part No. **8565925KIT**
Rack Stop
Replacement for Whirlpool



Part No. **809006501**
Seal (Lower)
22-1/2" length
Replacement for Electrolux



Part No. **154701001**
Splash Shield Kit
Replacement for Electrolux




Part No. **154568001**
Spray Arm (Lower)
Replacement for Electrolux



Part No. **5304506516**
Spray Arm (Upper)
Replacement for Electrolux



Part No. **5304517203**
Spray Arm (Lower)
Replacement for Electrolux



Part No. **5304518927**
Spray Arm
Replacement for Electrolux




Part No. **AGB73093001**
Spray Arm
Replacement for LG



Part No. **154430501**
Spring
Replacement for Electrolux



Part No. **675813**
Thermal Fuse
Replacement for Whirlpool



Part No. **8193762**
Thermal Fuse
Replacement for Whirlpool



Part No. **W10258275**
Thermal Fuse
Replacement for Whirlpool



Part No. **W10402110**
Thermal Fuse
Replacement for Whirlpool



Part No. **DD32-00005A**
Thermister
Replacement for Samsung



Part No. **661566**
Thermostat
Replacement for Whirlpool



Part No. **5304504077**
Water Level Switch
Replacement for Electrolux



Part No. **00628334**
Water Valve
Replacement for Bosch



Part No. **425458**
Water Valve
Replacement for Bosch



Part No. **607335**
Water Valve
Replacement for Bosch



Part No. **622058**
Water Valve
Replacement for Bosch



Part No. **5304525044**
Water Valve
Replacement for Electrolux

DISHWASHER




Part No. **5221DD1001E**
Water Valve
Replacement for LG



Part No. **8531669**
Water Valve
Replacement for Whirlpool




Part No. **154637401**
Water Valve
Replacement for Electrolux



Part No. **807047901**
Water Valve
Replacement for Electrolux



Part No. **DD62-00067A**
Water Valve
Replacement for Samsung



Part No. **DD62-00084A**
Water Valve
Replacement for Samsung



Part No. **W10158389**
Water Valve
Replacement for Whirlpool



Part No. **W10219643**
Water Valve
Replacement for Whirlpool




Part No. **W10327249**
Water Valve
Replacement for Whirlpool



Part No. **W11175771**
Water Valve
Replacement for Whirlpool



Part No. **WD15X10003**
Water Valve
Replacement for GE



Part No. **WD15X10011**
Water Valve
Replacement for GE



Part No. **33002032**

Baffle

Replacement for Whirlpool



Part No. **4400EL2001A**

Belt


Replacement for LG



Part No. **6602-001655**

Belt

Replacement for Samsung



Part No. **312959**

Belt

Replacement for Whirlpool



Part No. **341241**

Belt

Replacement for Whirlpool



Part No. **3394652**

Belt

Replacement for Whirlpool



Part No. **8544742**

Belt

Replacement for Whirlpool



Part No. **8547157**

Belt

Replacement for Whirlpool



Part No. **40111201**

Belt

Replacement for Whirlpool



Part No. **134719300**

Belt

Replacement for Electrolux



Part No. **137051400**

Belt

Replacement for Electrolux



Part No. **137292700**

Belt

Replacement for Electrolux



Part No. **W10136934**
Belt
Replacement for Whirlpool



Part No. **WE12X82**
Belt
Replacement for GE



Part No. **WE12X10015**
Belt
Replacement for GE



Part No. **303836**
Blower Wheel
Replacement for Whirlpool



Part No. **694089**
Blower Wheel
Replacement for Whirlpool



Part No. **B68C**
Brush (Vent Duct)
10 foot length, 4" diameter bristles



Part No. **W10328463**
Coil
Replacement for Whirlpool



Part No. **DE382**
Coil Kit (Primary & Secondary)
Universal Replacement



Part No. **W10861225**
Door Handle
Replacement for Whirlpool



Part No. **279570**
Door Latch
Replacement for Whirlpool



Part No. **279570M**
Door Latch
Replacement for Whirlpool



Part No. **3406105**
Door Switch (Lid)
Replacement for Whirlpool



Part No. **3406107**
Door Switch (Start)
Replacement for Whirlpool



Part No. **3406108**
Door Switch
Replacement for Whirlpool



Part No. **DC64-00828A**
Door Switch
Replacement for Samsung



Part No. **WE4M415**
Door Switch
Replacement for GE



Part No. **1153KIT**
Drum Bearing (Hub & Belt Kit)
Replacement for Electrolux



Part No. **5303281153**
Drum Bearing
Replacement for Electrolux



Part No. **WE3M26**
Drum Bearing (Front)
Replacement for GE



Part No. **WE25X205**
Drum Bearing Kit
Replacement for GE



Part No. **WE49X20697**
Drum Bearing Kit
Replacement for GE



Part No. **137513300KIT**
Drum Glide
Replacement for Electrolux



Part No. **37001298**
Drum Glide
Replacement for Whirlpool



Part No. **5303937139**
Drum Glide
Replacement for Electrolux



Part No. **279408**
Drum Seal
Replacement for Whirlpool



Part No. **279735**
Drum Seal
Replacement for Whirlpool



Part No. **5303937182**
Drum Seal
Replacement for Electrolux



Part No. **WE1M333**
Drum Slide
Replacement for GE



Part No. **WE1M1067**
Drum Slide
Replacement for GE



Part No. **5301EL1001G**
Element
Replacement for LG



Part No. **61927**
Element
Replacement for Whirlpool




Part No. **279838**
Element
Replacement for Whirlpool




Part No. **303404**
Element
Replacement for Whirlpool



Part No. **3387747**
Element
Replacement for Whirlpool



Part No. **4391960**
Element
Replacement for Whirlpool



Part No. **8544771**
Element
Replacement for Whirlpool



Part No. **134792700**
Element
Replacement for Electrolux




Part No. **137114000**
Element
Replacement for Electrolux



Part No. **5300622032**
Element
Replacement for Electrolux




Part No. **5300622034**
Element
Replacement for Electrolux



Part No. **DC47-00019A**
Element
Replacement for Samsung



Part No. **DC97-14486A**
Element
Replacement for Samsung



Part No. **LA1044**
Element
Replacement for Whirlpool



Part No. **33001807**
Felt
78-1/2" length
Replacement for Whirlpool



Part No. **5303283286**
Felt
48-1/2" length
Replacement for Electrolux



Part No. **WE09X20441**
Felt
46" length
Replacement for GE



Part No. **338906**
Flame Sensor
Replacement for Whirlpool



Part No. **110222**
Foil Duct (25 foot)
Exceeds UL[®] 181, Class 1 air connector label
Manufacturer assumes no responsibility for failure due to improper installation.
Please check your installation instructions and your local building codes for proper use.



Part No. **W10906683**

Gasket

Replacement for Whirlpool



Part No. **MEF62782201**

Hinge

Replacement for LG



Part No. **131863007**

Idler Pulley

Replacement for Electrolux



Part No. **134793511**

Idler Pulley

Replacement for Electrolux



Part No. **4560EL3001A**

Idler Pulley

Replacement for LG



Part No. **4561EL3002A**

Idler Pulley

Replacement for LG



Part No. **279640**

Idler Pulley

Replacement for Whirlpool



Part No. **691366**

Idler Pulley

Replacement for Whirlpool



Part No. **8547174**

Idler Pulley

Replacement for Whirlpool



Part No. **37001287**

Idler Pulley

Replacement for Whirlpool



Part No. **6-3700340**

Idler Pulley

Replacement for Whirlpool



Part No. **DC93-00634A**

Idler Pulley

Replacement for Samsung



Part No. **W10547292**
Idler Pulley
Replacement for Whirlpool




Part No. **W10837240**
Idler Pulley
Replacement for Whirlpool



Part No. **5318EL3001A**
Igniter
Replacement for LG



Part No. **31001556**
Igniter
Replacement for Whirlpool




Part No. **D510184P**
Igniter
Replacement for Alliance



Part No. **DC47-00022A**
Igniter
Replacement for Samsung



Part No. **UDI**
Igniter
Universal Replacement




Part No. **WE4M449**
Igniter
Replacement for GE



Part No. **WE4X444**
Igniter
Replacement for GE



Part No. **WE4X739**
Igniter
Replacement for GE



Part No. **WE4X750**
Igniter
Replacement for GE



Part No. **137544800**
Inlet Mist Valve
Replacement for Electrolux



Part No. **134844470**
Knob
 1-1/2" dia., 1/4" ext. shaft, 6 o'clock flat
 Replacement for Electrolux



Part No. **134886700**
Knob
 3" dia., flush shaft, 6 o'clock flat
 Replacement for Electrolux



Part No. **W11176265**
Knob
 1-7/8" dia., 3/8" ext. shaft, 12 o'clock flat
 Replacement for Whirlpool



Part No. **WE01X10160**
Knob
 2" dia., 3/4" ext. shaft, 6 o'clock flat
 Replacement for GE



Part No. **WE01X20374**
Knob
 2-3/4" dia., 1/8" ext. shaft, 12 o'clock flat
 Replacement for GE



Part No. **WE1M654**
Knob
 2-3/4" dia., 1/8" ext. shaft, 12 o'clock flat
 Replacement for GE



Part No. **WE1X1263**
Knob
 2-7/8" dia., 1/8" ext. shaft, 12 o'clock flat
 Replacement for GE



Part No. **DVC202PK**
Linteater (Vent Cleaning)
 Removes lint build up
 Helps prevent dryer fires
 Easy to use with your cordless drill
 Sold in 6PK ONLY



Part No. **EXT12FT**
Linteater Extension Kit
 4 - 36" flexible rods
 Screw together to reach into vents up to
 12 feet from dryer



Part No. **00652184**
Lint Filter
 Replacement for Bosch



Part No. **5231EL1003B**
Lint Filter
 Replacement for LG



Part No. **8531964**
Lint Filter
 Replacement for Whirlpool



Part No. **8572270**
Lint Filter
Replacement for Whirlpool




Part No. **5304516871**
Lint Filter
Replacement for Electrolux



Part No. **ADQ56656401**
Lint Filter
Replacement for LG



Part No. **W10120998**
Lint Filter
Replacement for Whirlpool



Part No. **W10516085**
Lint Filter
Replacement for Whirlpool



Part No. **W10828351**
Lint Filter
Replacement for Whirlpool




Part No. **WE03X23881**
Lint Filter
Replacement for GE



Part No. **WE18X25100**
Lint Filter
Replacement for GE



Part No. **53-0918**
Lint Screen
Replacement for Whirlpool



Part No. **339392**
Lint Screen
Replacement for Whirlpool



Part No. **349639**
Lint Screen
Replacement for Whirlpool



Part No. **8557884**
Lint Screen
Replacement for Whirlpool



Part No. **33001003**
Lint Screen
Replacement for Whirlpool



Part No. **33001808**
Lint Screen
Replacement for Whirlpool



Part No. **33002970**
Lint Screen
Replacement for Whirlpool



Part No. **W10717210**
Lint Screen
Replacement for Whirlpool



Part No. **WE18X26**
Lint Screen
Replacement for Whirlpool



Part No. **DC31-00055G**
Motor
2-1/4" shaft
Replacement for Samsung



Part No. **279393**
Nut & Bolt Kit
Replacement for Whirlpool



Part No. **4392065**
Rebuild Kit
Replacement for Whirlpool



Part No. **3700KIT2**
Repair Kit
Replacement for Whirlpool



Part No. **4392067**
Repair Kit
Replacement for Whirlpool



Part No. **4581KIT**
Repair Kit
Replacement for LG



Part No. **DC97KIT4**
Repair Kit
Replacement for Samsung



Part No. **4581EL2002C**
Roller
Replacement for LG



Part No. **4581EL2002H**
Roller
Replacement for LG



Part No. **303373K**
Roller
Replacement for Whirlpool



Part No. **349241**
Roller
Replacement for Whirlpool



Part No. **349241T**
Roller
Replacement for Whirlpool



Part No. **12001541**
Roller
Replacement for Whirlpool



Part No. **37001042**
Roller
Replacement for Whirlpool



Part No. **134715900**
Roller
Replacement for Electrolux



Part No. **DC97-16782A**
Roller
Replacement for Samsung



Part No. **W10314173**
Roller
Replacement for Whirlpool



Part No. **WE03X10016**
Roller
Replacement for GE




Part No. **LA1008**
Roller Kit
Replacement for Whirlpool



Part No. **W10359269**
Roller Shaft
Replacement for Whirlpool



Part No. **W10359272**
Roller Shaft
Replacement for Whirlpool



Part No. **SKK-7A**
Stacking Kit
Replacement for Samsung



Part No. **280148**
Thermal Cut
Replacement for Whirlpool



Part No. **W10167627**
Thermal Cut
Replacement for Whirlpool



Part No. **W11050897**
Thermal Cut
Replacement for Whirlpool



Part No. **197**
Thermal Cut Off Kit
Replacement for Whirlpool



Part No. **279816**
Thermal Cut Off Kit
Replacement for Whirlpool




Part No. **279769**
Thermal Fuse
Replacement for Whirlpool



Part No. **279973**
Thermal Fuse
Replacement for Whirlpool



Part No. **3390719**
Thermal Fuse
Replacement for Whirlpool



Part No. **3392519**
Thermal Fuse
Replacement for Whirlpool



Part No. **3399849**
Thermal Fuse
Replacement for Whirlpool



Part No. **40113801**
Thermal Fuse
Replacement for Whirlpool



Part No. **134120900**
Thermal Fuse
Replacement for Electrolux




Part No. **137032600**
Thermal Fuse
Replacement for Electrolux



Part No. **137539200**
Thermal Fuse
Replacement for Electrolux



Part No. **DC47-00016A**
Thermal Fuse
Replacement for Samsung



Part No. **W10909685**
Thermal Fuse
Replacement for Whirlpool



Part No. **LA1053**
Thermal Fuse Kit
Replacement for Whirlpool



Part No. **8577274**
Thermistor
Replacement for Whirlpool



Part No. **DC32-00007A**
Thermistor
Replacement for Samsung



Part No. **3204267**
Thermostat
Replacement for Electrolux



Part No. **3387134**
Thermostat
Replacement for Whirlpool



Part No. **3977767**
Thermostat
Replacement for Whirlpool



Part No. **6931EL3001E**
Thermostat
Replacement for LG



Part No. **6931EL3001F**
Thermostat
Replacement for LG



Part No. **6931EL3003C**
Thermostat
Replacement for LG



Part No. **6931EL3003D**
Thermostat
Replacement for LG



Part No. **6931EL3004B**
Thermostat
Replacement for LG



Part No. **694674**
Thermostat
Replacement for Whirlpool



Part No. **8557403**
Thermostat
Replacement for Whirlpool



Part No. **DC47-00017A**
Thermostat
Replacement for Samsung



Part No. **DC47-00018A**
Thermostat
Replacement for Samsung



Part No. **DC96-00887C**
Thermostat
Replacement for Samsung



Part No. **L290**
Thermostat
Universal Replacement



Part No. **W10116735**
Thermostat
Replacement for Whirlpool



Part No. **WE4M160**
Thermostat
Replacement for GE



Part No. **W10185970**
Timer
Replacement for Whirlpool



Part No. **W10185972**
Timer
Replacement for Whirlpool



Part No. **W10185976**
Timer
Replacement for Whirlpool



Part No. **W10185981**
Timer
Replacement for Whirlpool



Part No. **W10185982**
Timer
Replacement for Whirlpool



Part No. **W10185992**
Timer
Replacement for Whirlpool



Part No. **W10186032**
Timer
Replacement for Whirlpool



Part No. **W10436303**
Timer
Replacement for Whirlpool



Part No. **W10745655**
Timer
Replacement for Whirlpool



Part No. **WCOIL**
A/C Coil Cleaner
 20 oz.
 For A/C and heat pump coils



Part No. **LA11AA005**
Blower Wheel
 4" diameter
 Replacement for Carrier



Part No. **0130F00010KIT**
Flame Sensor (6pk)
 Replacement for Goodman



Part No. **18G89**
Flame Sensor
 Replacement for Lennox



Part No. **52W29**
Flame Sensor
 Replacement for Lennox



Part No. **69W43**
Flame Sensor
 Replacement for Lennox



Part No. **98M87**
Flame Sensor
 Replacement for Lennox




Part No. **LH680014**
Flame Sensor
 Replacement for Carrier



Part No. **SEN01114**
Flame Sensor
 Replacement for Trane



Part No. **02532625000**
Furnace Igniter
 Replacement for York



Part No. **1090**
Furnace Igniter
 Universal Replacement



Part No. **1408**
Furnace Igniter
 Universal Replacement







Part No. **1409**
Furnace Igniter
Universal Replacement



Part No. **20165703S**
Furnace Igniter
Replacement for Goodman



Part No. **903758**
Furnace Igniter
Replacement for Whirlpool



Part No. **B1401018S**
Furnace Igniter
Replacement for Goodman



Part No. **IG101**
Furnace Igniter
Universal Replacement



Part No. **H-301**
Ice Machine Cleaner
1 gallon
Nickel safe - meets Manitowac spec. GES-6



Part No. **H-316**
Ice Machine Cleaner
1 pint
Nickel safe - meets Manitowac spec. GES-6



Part No. **1003**
Ignition Module
24VAC, 50/60 Hz
Prepurge: 1 sec.
90 sec. trial, 5 min. retry
Universal Replacement



Part No. **87F16**
Limit Switch
Replacement for Lennox



Part No. **60J00**
Ignition Module
24VAC, 50/60 Hz
Replacement for Lennox




Part No. **B1859005**
Motor (Blower)
115V, 60 Hz, 3000 RPM
Replacement for Janitrol




Part No. **14Y70**
Motor (Condenser Fan)
Replacement for Lennox



Part No. **1013833**
Motor (Inducer)
 115V, 60 Hz, 1.47 amps, 1/35 HP
 Replacement for Heil



Part No. **318984-753**
Motor (Inducer)
 115V, 1.8 amps, 3300 RPM
 Replacement for Carrier



Part No. **LH680005**
Pilot Assembly
 Replacement for Carrier



Part No. **SHUBEE**
Shoe Covers (Dark Blue)
 Sold in 50pk ONLY



*For professional use only:
 Always wear safety glasses
 and protective gloves. Use in
 compliance with the
 Montreal Protocol and
 Regional or Federal laws for
 the handling of refrigerant.*

Part No. **944KIT**
Super Seal (HVACR)
 Repairs leaks in refrigerant units utilizing more
 than 4 lbs. of refrigerant
 1-1/2 ton up to 5 ton (min. of 30 oz. of oil req.)
 Compatible w/all refrigerants & oils includ. 410a



*For professional use only:
 Always wear safety glasses
 and protective gloves. Use in
 compliance with the
 Montreal Protocol and
 Regional or Federal laws for
 the handling of refrigerant.*

Part No. **947KIT**
Super Seal (ACR) 1 unit
 Repairs leaks in refrigerant units utilizing less than
 4 lbs. of refrigerant
 230 BTUH up to 18000 BTUH (1-1/2 ton)
 (min. of 10 oz. of oil required)
 Compatible with all refrigerants & oils including 410a



Part No. **ZC-02**
Zip-Clean Coil Cleaner
 18 oz.
 Cleans evaporator coils quickly & easily
 Prevents future dirt build up



Part No. **ZS75**
Zoom Spout Oiler
 4 oz.
 All purpose turbine oil
 Spout applicator telescopes to 14"



Part No. **26QBP0213**
Bulb
120V, 20 watts, 1-5/8" high



Part No. **26QBP0264**
Bulb
130V, 40 watts, 2-5/8" high



Part No. **26QBP0930**
Bulb
120V, 20 watts, 2-1/4" high



Part No. **26QBP3236**
Bulb
130V, 40 watts, 2-7/8" high



Part No. **26QBP4076**
Bulb
120V, 30 watts, 2-3/16" high



Part No. **26QBP4093**
Bulb
130V, 40 watts, 2-1/4" high



Part No. **WB08X10057**
Bulb
130V, 50 watts, 1-5/8" high



Part No. **13QBP21090**
Capacitor (High Voltage)
2100V, 0.90 μ f, 1/4" terminal size



Part No. **13QBP21095**
Capacitor (High Voltage)
2100V, 0.95 μ f 1/4" terminal size



Part No. **13QBP21100**
Capacitor (High Voltage)
2100V, 1.00 μ f 1/4" terminal size



Part No. **13QBP21105**
Capacitor (High Voltage)
2100V, 1.05 μ f 1/4" terminal size



Part No. **14QBP20CFB**
Ceramic Fuse (Fast blow)
250V, 20 amp, 1-1/4" length

Part No. **14QBP20CSB**
Ceramic Fuse (Slow blow)
250V, 20 amp, 1-1/4" length



Part No. **11QBP0236**
Diode (High Voltage)
 3-1/2" length, 12 kV, 350 mA



Part No. **11QBPUNIV**
Diode (High Voltage)
 3-5/8" length, 12 kV, 350 mA



Part No. **DE91-70063D**
Diode
 Replacement for Samsung



Part No. **25QBP3779**
Door Handle
 11-5/8" length x 1-1/8" width
 Replacement for GE #WB15X10020



Part No. **25QBP3780**
Door Handle
 11-5/8" length x 1-1/8" width
 Replacement for GE #WB15X335



Part No. **25QBP3784**
Door Handle
 11-3/16" length x 1-1/8" width
 Replacement for GE #WB15X10022




Part No. **25QBP3785**
Door Handle
 11-3/16" length x 1-1/8" width
 Replacement for GE #WB15X10023




Part No. **4750**
Magic Lights Microwave Tester
 Checks microwave power settings
 Finds hot and cold spots
 No batteries needed




Part No. **10QBP0228**
Magnetron
 4.1 kV, 700-800 watts, Compact type, K Configuration, 30mm antenna



Part No. **10QBP0229**
Magnetron
 4.1 kV, 700-850 watts, Standard type, J Configuration, 30mm antenna






Part No. **10QBP0230**

Magnetron


4.1 kV, 700-850 watts, Standard type, J Configuration, 30mm antenna



Part No. **10QBP0231**

Magnetron


4.1 kV, 700-850 watts, Standard type, H Configuration, 30mm antenna



Part No. **10QBP0232**

Magnetron


4.1 kV, 700-850 watts, Standard type, K Configuration, 30mm antenna



Part No. **10QBP0234**

Magnetron



4.1 kV, 700-800 watts, Compact type, J Configuration, 30mm antenna



Part No. **10QBP0235**

Magnetron


4.1 kV, 700-850 watts, Standard type, E Configuration, 30mm antenna



Part No. **10QBP1000**

Magnetron


4.35 kV, 900-1000 watts, Standard type, J Configuration, 30mm antenna



Part No. **10QBP1003**

Magnetron


4.35 kV, 900-1000 watts, Standard type, H Configuration, 30mm antenna



Part No. **10QBP1004**

Magnetron

4.35 kV, 900-1000 watts, Standard type, K Configuration, 30mm antenna



Part No. **10QBP1006**
Magnetron

4.35 kV, 1000 watts, Standard type, J Configuration, 30mm antenna



Part No. **98QBP0300**
Paint (Spray)

6 oz., Pearl/Off White
Formulated specifically for use on microwaves



Part No. **98QBP0302**
Paint (Spray)

6 oz., Snow/Bright White
Formulated specifically for use on microwaves



Part No. **98QBP0303**
Paint (Touch Up)

1/2 oz. with brush, Snow/Bright White
Formulated specifically for use on microwaves



Part No. **28QBP0491**
Switch (Button Type)

Latch Application
SPST NO, 22 amps, 125/250V
.020 x .187 terminal



Part No. **28QBP0495**
Switch (Button Type)

Universal Application
SPDT NO/NC, 16 amps, 125/250V
.020 x .187 terminal



Part No. **28QBP0496**
Switch (Button Type)

Universal Application
SPDT NO/NC, 16 amps, 125/250V
.320 x .250 terminal



Part No. **28QBP0497**
Switch (Button Type)

Latch Application
SPST NO, 16 amps, 125/250V
.020 x .187 terminal



Part No. **28QBP0499**
Switch (Button Type)

Latch Application
SPST NO, 16 amps, 125/250V
.020 x .187 terminal



Part No. **5304509457**
Switch Holder
Replacement for Electrolux




Part No. **DE47-20034A**
Thermostat
Replacement for Samsung



Part No. **DE47-20060A**

Thermostat

Replacement for Samsung



Part No. **4452395**

Torsion Spring

Replacement for Whirlpool

Part No. **4452396**

Torsion Spring

Replacement for Whirlpool



Part No. **WB26X10038**

Turntable Motor

Replacement for GE



Part No. **30QBP1848**

Turntable Tray

12-1/2" diameter
Replaces GE #WB39X10003



Part No. **30QBP4185**

Turntable Tray

11-7/8" diameter
Replaces Whirlpool #4393799




Part No. **40QBP1012**

Waveguide Cover

15-3/8" x 9-1/2"
Cut to fit, Mica construction
Universal Replacement


REFRIGERATION




Part No. **EAFCBF**
Air Filter
 Replacement for Electrolux



Part No. **WR02X12208**
Appliance Bulb
 12V, 6 watt, 1-7/8" high



Part No. **DA41-00676J**
Assembly Lamp
 Replacement for Samsung



Part No. **EBR71326804**
Assembly Sensor
 Replacement for LG



Part No. **4388736**
Auger Drum
 Replacement for Whirlpool



Part No. **W10321304**
Bin (Clear)
 Replacement for Whirlpool



Part No. **5304464438**
Capacitor
 Replacement for Electrolux



Part No. **W10350564**
Capacitor
 Replacement for Whirlpool



Part No. **WR55X24064**
Capacitor
 Replacement for GE



Part No. **2198202**
Cold Control
 Replacement for Whirlpool



Part No. **2200859**
Cold Control
 Replacement for Whirlpool



Part No. **241537103**
Cold Control
 Replacement for Electrolux



Part No. **5304404821**
Cold Control
Replacement for Electrolux



Part No. **5304421256**
Cold Control
Replacement for Electrolux



Part No. **5304513033**
Cold Control
Replacement for Electrolux



Part No. **W10583800**
Cold Control
Replacement for Whirlpool



Part No. **W11088945**
Cold Control
Replacement for Whirlpool




Part No. **WR09X10042**
Cold Control
Replacement for GE




Part No. **WR9X355**
Cold Control
Replacement for GE



Part No. **WR9X491**
Cold Control
Replacement for GE



Part No. **2304099**
Control Board
Replacement for Whirlpool



Part No. **W10352689**
Control Board
Replacement for Whirlpool



Part No. **241993001**
Crisper Support
Replacement for Electrolux




Part No. **241993101**
Crisper Support
Replacement for Electrolux



Part No. **2263749**
Defrost Heater
 Calrod, 475 watts @ 120V
 Replacement for Whirlpool



Part No. **2323198**
Defrost Heater
 Calrod, 614 watts @ 120V
 Replacement for Whirlpool




Part No. **61001846**
Defrost Heater
 Quartz Tube, 575 watts @ 115V
 10-3/8" tube length
 Replacement for Whirlpool




Part No. **242044020**
Defrost Heater
 Calrod, 375 watts @ 115V
 Replacement for Electrolux



Part No. **242044113**
Defrost Heater
 Calrod, 450 watts @ 115V
 Replacement for Electrolux



Part No. **DA47-00244B**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung




Part No. **DA47-00244D**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung




Part No. **DA47-00244Q**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung



Part No. **DA47-00244U**
Defrost Heater
 Calrod, 100 watts @ 120V
 Replacement for Samsung



Part No. **DA47-00244W**
Defrost Heater
 Calrod, 120 watts @ 120V
 Replacement for Samsung



Part No. **DA47-00322J**
Defrost Heater
 Calrod, 120 watts @ 120V
 Replacement for Samsung




Part No. **DA47-00424A**
Defrost Heater
 Calrod, 240 watts @ 115V
 Replacement for Samsung




Part No. **DA47-00424B**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung



Part No. **DA47-00424L**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung



Part No. **DA47-00434A**
Defrost Heater
 Calrod, 120 watts @ 115V
 Replacement for Samsung



Part No. **WR51X442**
Defrost Heater
 Quartz Tube, 600 watts @ 115V
 9-1/2" tube length
 Replacement for GE



Part No. **WR51X443**
Defrost Heater
 Quartz Tube, 770 watts @ 115V
 12-13/16" tube length
 Replacement for GE



Part No. **WR51X10038**
Defrost Heater
 Quartz Tube, 375 watts @ 115V
 21" tube length
 Replacement for GE



Part No. **WR51X10055**
Defrost Heater
 Quartz Tube, 725 watts @ 115V
 12" tube length
 Replacement for GE




Part No. **4387490**
Defrost Thermostat
 L58-14F, 5/16" side push on clip
 24" leads with stripped wire ends
 Replacement for Whirlpool



Part No. **4387503**
Defrost Thermostat
 L62-14C, 3/8" side push on clip
 6" leads with stripped wire ends
 Replacement for Whirlpool



Part No. **67003426**
Defrost Thermostat
 L42-30C, 1/4" side push on clip
 7-1/2" & 24-1/2" leads w/ stripped wire ends
 Replacement for Whirlpool



Part No. **218969902**
Defrost Thermostat
 L47-22F, 5/16" side push on clip
 Bullet connectors
 Replacement for Electrolux



Part No. **5303918202**
Defrost Thermostat
 L47-22C, 5/16" side push on clip
 4" & 6" leads with stripped wire ends
 Replacement for Electrolux



Part No. **5303918214**

Defrost Thermostat

L47-22C, 1/4" side push on clip
6" leads with stripped wire ends
Replacement for Electrolux



Part No. **DA47-00243K**

Defrost Thermostat

Replacement for Samsung



Part No. **DA47-00285P**

Defrost Thermostat

Replacement for Samsung



Part No. **MLT45**

Defrost Thermostat

Open@45 Close@25
24" leads with stripped wire ends
Universal Replacement



Part No. **MLT50**

Defrost Thermostat

Open@50 Close@30
24" leads with stripped wire ends
Universal Replacement



Part No. **MLT55**

Defrost Thermostat


Open@55 Close@35
24" leads with stripped wire ends
Universal Replacement



Part No. **MLT60**

Defrost Thermostat

Open@60 Close@40
24" leads with stripped wire ends
Universal Replacement



Part No. **W10165425**

Defrost Thermostat

L42-30F, 1/2" side push on clip
15-1/4" & 25" leads with stripped wire ends
Replacement for Whirlpool



Part No. **W10225581**

Defrost Thermostat

L60-32C, 1/4" side push on clip
11-3/4" leads with stripped wire ends
Replacement for Whirlpool



Part No. **WR50X10025**

Defrost Thermostat

L58-30F, 1/4" side push on clip
4-1/2" & 15-1/2" leads with stripped wire ends
Replacement for GE



Part No. **WR50X10068**

Defrost Thermostat

L140-30C, 5/16" side push on clip
11" leads with stripped wire ends
Replacement for GE



Part No. **WR50X10108**

Defrost Thermostat

L140-30F, 1/2" side push on clip
14" & 17" leads with stripped wire ends
Replacement for GE




Part No. **2183400**
Defrost Timer
 8 hr. 25 min.
 Replacement for Whirlpool



Part No. **215846602**
Defrost Timer
 8 hr. 30 min.
 Replacement for Electrolux




Part No. **241705102**
Defrost Timer
 12 hr. 25 min.
 Replacement for Electrolux



Part No. **5304518034**
Defrost Timer
 12 hr.
 Replacement for Electrolux



Part No. **GP1**
Defrost Timer
 6 hr. 21 min.
 Universal Replacement



Part No. **GP11**
Defrost Timer
 8 hr. 21 min.
 Universal Replacement



Part No. **W10822278**
Defrost Timer
 8 hr. 21 min.
 Replacement for Whirlpool



Part No. **WR09X10049**
Defrost Timer
 15 hr. 34 min.
 Replacement for GE



Part No. **WR9X480**
Defrost Timer
 6 hr. 30 min.
 Replacement for GE



Part No. **WR9X483**
Defrost Timer
 10 hr. 30 min.
 Replacement for GE



Part No. **WR9X489**
Defrost Timer
 16 hr. 35 min.
 Replacement for GE



Part No. **WR9X502**
Defrost Timer
 8 hr. 30 min.
 Replacement for GE

REFRIGERATION



Part No. **WR9X520**
Defrost Timer
 5 hr. 44 min.
 Replacement for GE




Part No. **215366002**
Door Bar
 30-3/4" x 1-11/16"
 Replacement for Electrolux



Part No. **WR71X10077**
Door Bar
 24-1/2" x 2"
 Replacement for GE



Part No. **240338001**
Door Bin
 24-3/8" x 6-1/4"
 Replacement for Electrolux




Part No. **8201756**
Door Chute Kit
 Replacement for Whirlpool



Part No. **240457701**
Door Closing Cam
 Replacement for Electrolux

Measurements are from end to end and not exact, to make sure you get the correct gasket, always go by model number.



* Due to shipping concerns, you must order a minimum of 2 rigid style gaskets (you may mix and match)



FRONT CORNER
 BACK CORNER

Part No. **2159057***
Door Gasket (Fresh Food, White)
 34-3/4" W x 47" L
 Replacement for Whirlpool



FRONT CORNER
 BACK CORNER

Part No. **2159061***
Door Gasket (Fresh Food, White)
 34-1/2" W x 47-1/4" L
 Replacement for Whirlpool



FRONT CORNER
 BACK CORNER

Part No. **2159327**
Door Gasket (Freezer, White)
 19-3/4" W x 28-1/8" L
 Replacement for Whirlpool




FRONT CORNER
 BACK CORNER

Part No. **2188436A**
Door Gasket (Freezer, White)
 27-1/8" W x 60" L
 Replacement for Whirlpool



FRONT CORNER
 BACK CORNER

Part No. **2188448A**
Door Gasket (Fresh Food, Beige)
 8" W x 32-1/4" L
 Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **2188462A**

Door Gasket (Freezer, White)

18-3/4" W x 27" L

Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER

Part No. **2262080**

Door Gasket (Fresh Food, White)

8" W x 32-1/4" L

Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **2319264T***

Door Gasket (Fresh Food, White)

12" W x 30-1/4" L

Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **2319265T***

Door Gasket (Fresh Food, White)

12" W x 30-1/2" L

Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **2319266T***

Door Gasket (Fresh Food, White)

12" W x 30-1/2" L

Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **10359708Q**

Door Gasket (Fresh Food, White)

19" W x 31-1/2" L

Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **12550109Q**

Door Gasket (Fresh Food, White)

28-1/4" W x 39-1/2" L

Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **12550111Q**

Door Gasket (Fresh Food, White)

31-1/8" W x 41-1/4" L

Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **12550115Q**

Door Gasket (Fresh Food, White)

8" W x 32-1/4" L

Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **12550116Q**

Door Gasket (Freezer, White)

23-3/8" W x 30-7/8" L

Replacement for Whirlpool



FRONT
CORNER


BACK
CORNER

Part No. **61004003**

Door Gasket (Fresh Food, White)

12" W x 30-1/2" L

Replacement for Whirlpool



FRONT
CORNER

BACK
CORNER

Part No. **61004008**


Door Gasket (Fresh Food, White)

12" W x 30-1/2" L


Replacement for Whirlpool

REFRIGERATION


Measurements are from end to end and not exact, to make sure you get the correct gasket, always go by model number.




* Due to shipping concerns, you must order a minimum of 2 rigid style gaskets (you may mix and match)




Part No. **218730603**
Door Gasket (Fresh Food, White)
 12-3/4" W x 30-1/2" L
 Replacement for Electrolux




Part No. **241872501** *
Door Gasket (Freezer, White)
 18-3/4" W x 29-3/4" L
 Replacement for Electrolux




Part No. **241872502** *
Door Gasket (Fresh Food, White)
 27-1/2" W x 37" L
 Replacement for Electrolux



Part No. **241872503** *
Door Gasket (Freezer, White)
 19" W x 31-1/2" L
 Replacement for Electrolux



Part No. **241872504** *
Door Gasket (Fresh Food, White)
 18-3/4" W x 29-3/4" L
 Replacement for Electrolux



Part No. **241872505** *
Door Gasket (Freezer, White)
 20-1/2" W x 28-1/2" L
 Replacement for Electrolux




Part No. **241872509** *
Door Gasket (Freezer, Black)
 18" W x 28-1/2" L
 Replacement for Electrolux




Part No. **241872510** *
Door Gasket (Fresh Food, Black)
 27" W x 41" L
 Replacement for Electrolux




Part No. **241872512** *
Door Gasket (Fresh Food, Black)
 28-5/8" W x 41-3/4" L
 Replacement for Electrolux




Part No. **241872513** *
Door Gasket (Fresh Food, White)
 29-3/4" W x 42-3/4" L
 Replacement for Electrolux




Part No. **DA97-05253B**
Door Gasket (Fresh Food, Gray)
 17" W x 39-1/2" L
 Replacement for Samsung




Part No. **DA97-05557Y**
Door Gasket (Freezer, Gray)
 23-1/2" W x 34-3/4" L
 Replacement for Samsung




Part No. **WR14X27230**
Door Gasket (Freezer, White)
 17-1/4" W x 26-5/8" L
 Replacement for GE




Part No. **WR24X445**
Door Gasket (Freezer, White)
 21-1/2" W x 29-1/2" L
 Replacement for GE



Part No. **WR24X446**
Door Gasket (Fresh Food, White)
 8" W x 32" L
 Replacement for GE



Part No. **WR24X449**
Door Gasket (Freezer, White)
 19-1/4" W x 27-1/2" L
 Replacement for GE



Part No. **WR24X450**
Door Gasket (Fresh Food, White)
 8" W x 32" L
 Replacement for GE



Part No. **WR24X10186**
Door Gasket (Fresh Food, White)
 11-7/8" W x 30-1/2" L
 Replacement for GE



Part No. **WR24X10228**
Door Gasket (Freezer, White)
 11-3/4" W x 30-1/2" L
 Replacement for GE



Part No. **WR24X10229**
Door Gasket (Fresh Food, White)
 12" W x 30-1/2" L
 Replacement for GE



Part No. **WR24X10231**
Door Gasket (Fresh Food, White)
 11-3/4" W x 30-1/2" L
 Replacement for GE



Part No. **WR24X10236**
Door Gasket (Fresh Food, White)
 12" W x 30-1/2" L
 Replacement for GE



Part No. **6600JB3007E**
Door Switch
 Replacement for LG

REFRIGERATION



Part No. **6600JB3007K**
Door Switch
Replacement for LG



Part No. **18806**
Door Switch



Part No. **6600JB1010A**
Door Switch
Replacement for LG



Part No. **DA34-00041B**
Door Switch
Replacement for Samsung



Part No. **DA97-04049E**
Drain Cap
Replacement for Samsung



Part No. **W10619951**
Drain Tube
Replacement for Whirlpool



Part No. **WR2X9144**
Endcap
Replacement for GE



Part No. **2183141**
Endcap (Handle)
Replacement for Whirlpool



Part No. **2163777**
Fan Blade
Replacement for Whirlpool



Part No. **2169142**
Fan Blade
Replacement for Whirlpool



Part No. **WR60X30922**
Fan Blade
Replacement for GE



Part No. **241920106**
Fill Tube
Replacement for Electrolux



Part No. **5304506469**
Handle Set
 Replacement for Electrolux



Part No. **5304506471**
Handle Set
 Replacement for Electrolux



Part No. **PU410**
Hard Start System
 120V, 1/4 and 1/3 HP
 Will work with or without a run capacitor




Part No. **819043**
Heat Probe
 Replacement for Whirlpool




Part No. **WR13X10020**
Hinge Pin
 Replacement for GE



Part No. **241798224**
Ice Maker
 Replacement for Electrolux



Part No. **243297606**
Ice Maker
 Replacement for Electrolux




Part No. **5303918277**
Ice Maker
 Replacement for Electrolux



Part No. **5303918344**
Ice Maker
 Replacement for Electrolux



Part No. **AEQ72909603**
Ice Maker
 Replacement for LG



Part No. **AEQ73209906**
Ice Maker
 Replacement for LG



Part No. **GEIM**
Ice Maker
 Replacement for GE

REFRIGERATION




Part No. **WIM**
Ice Maker
Replacement for Whirlpool



Part No. **WR30X10093**
Ice Maker
Replacement for GE



Part No. **WR17X11705**
Ice Maker Auger
Replacement for GE



Part No. **4389102**
Ice Maker Board
Replacement for Whirlpool



Part No. **IMKR8**
Ice Maker PEX Line
Universal Replacement



Part No. **WR62X10055**
Ice Maker Solenoid
Replacement for GE



Part No. **D7813010**
Ice Maker Wiring Harness
Replacement for Whirlpool



Part No. **W11338583**
Light Bulb



Part No. **2212363**
Motor (Auger)
Replacement for Whirlpool




Part No. **2252130**
Motor (Auger)
Replacement for Whirlpool



Part No. **2315547**
Motor (Auger)
Replacement for Whirlpool



Part No. **2322580**
Motor (Auger)
Replacement for Whirlpool




Part No. **242221501**
Motor (Auger)
 Replacement for Electrolux



Part No. **W11117906**
Motor (Auger)
 Replacement for Whirlpool



Part No. **W11202789**
Motor (Auger)
 Replacement for Whirlpool



Part No. **4681JB1029D**
Motor (Condensor)
 13V, 120mA, CCW, 2" shaft
 Replacement for LG



Part No. **W10124096**
Motor (Condensor)
 115V, 4.1W, 60Hz, 1-3/8" shaft
 Replacement for Whirlpool



Part No. **WR60X10168**
Motor (Condensor)
 115V, 60 Hz, 11W, .193A, 2200RPM, 1-3/4" shaft
 Replacement for GE



Part No. **WR60X10209**
Motor (Condensor)
 115V, 2.2W, 2" shaft
 Replacement for GE



Part No. **WR60X10220**
Motor (Condensor)
 115V, 60 Hz, .29A, 3000RPM, 1-3/8" shaft
 Replacement for GE




Part No. **WR60X10348**
Motor (Condensor)
 115V, 60 Hz, 2" shaft
 Replacement for GE



Part No. **EAU59551204**
Motor (DC)
 Replacement for LG



Part No. **3-60336-001**
Motor (Evaporator)
 115V, 60 Hz, 4.2W, 1-1/2" shaft
 Replacement for Whirlpool




Part No. **4681JB1027C**
Motor (Evaporator)
 13VDC, 3.1W, .24A, 1-7/8" shaft
 Replacement for LG


REFRIGERATION



Part No. **4681JB1029B**
Motor (Evaporator)
 13V, 150mA, CCW, 2-3/4" shaft
 Replacement for LG



Part No. **4681JB1029H**
Motor (Evaporator)
 13VDC, 3W, 230mA, CCW, 1-7/8" shaft
 Replacement for LG



Part No. **482469**
Motor (Evaporator)
 120V, 60 Hz, .29A, 3000 RPM, 3/4" shaft
 Replacement for Whirlpool



Part No. **482731**
Motor (Evaporator)
 120V, 60 Hz, .26A, 3000 RPM, 3/4" shaft
 Replacement for Whirlpool



Part No. **2188874**
Motor (Evaporator)
 115V, 60 Hz, 4.1W, 1-1/4" shaft
 Replacement for Whirlpool



Part No. **2315549**
Motor (Evaporator)
 115V, 60 Hz, 1-3/4" shaft
 Replacement for Whirlpool



Part No. **4389144**
Motor (Evaporator)
 120V, 60 Hz, .14A, 3000 RPM, 1-3/8" shaft
 Replacement for Whirlpool



Part No. **12002744**
Motor (Evaporator)
 120V, 60 Hz, .14A, 3000 RPM, 1-3/8" shaft
 Replacement for Whirlpool




Part No. **61004888**
Motor (Evaporator)
 120V, 60 Hz, .21A, 3000 RPM, 1-1/8" shaft
 Replacement for Whirlpool



Part No. **61005935**
Motor (Evaporator)
 120V, 60 Hz, .21A, 3000 RPM, 1-1/8" shaft
 Replacement for Whirlpool




Part No. **240369701**
Motor (Evaporator)
 120V, 60 Hz, .135A, 3000 RPM, 1-3/4" shaft
 Replacement for Electrolux



Part No. **241509402**
Motor (Evaporator)
 1-3/4" shaft
 Replacement for Electrolux




Part No. **241854301**
Motor (Evaporator)
 120V, 60 Hz, .1A, 6W, 1-3/4" shaft
 Replacement for Electrolux




Part No. **242077705**
Motor (Evaporator)
 115V, 60 Hz, 3W, 1-3/8" shaft
 Replacement for Electrolux




Part No. **242219204**
Motor (Evaporator)
 115V, 60 Hz, .33W, 2600RPM, 1-3/4" shaft
 Replacement for Electrolux




Part No. **297250000**
Motor (Evaporator)
 115V, 60 Hz, .18A, 8W, 1-1/4" shaft
 Replacement for Electrolux



Part No. **808602601**
Motor (Evaporator)
 120V, 60 Hz, .1A, 6W, 1-7/8" shaft
 Replacement for Electrolux



Part No. **5300158289**
Motor (Evaporator)
 120V, 60 Hz, .28A, 3000RPM, 1-3/8" shaft
 Replacement for Electrolux



Part No. **5303918549**
Motor (Evaporator)
 120V, 60 Hz, .1A, 6W, 1-3/4" shaft
 Replacement for Electrolux



Part No. **DA31-00146B**
Motor (Evaporator)
 12VDC, 2.5W, .21A, 1550RPM, 1-3/4" shaft
 Replacement for Samsung



Part No. **DA31-00146E**
Motor (Evaporator)
 12VDC, 3.21W, 2520RPM, 1-1/2" shaft
 Replacement for Samsung



Part No. **DA31-00146H**
Motor (Evaporator)
 12VDC, 2.1W, 0.176A, 2950RPM, 1-1/2" shaft
 Replacement for Samsung



Part No. **DA31-00146J**
Motor (Evaporator)
 12VDC, 2.8W, 1920RPM, 2" shaft
 Replacement for Samsung



Part No. **DA31-00334A**
Motor (Evaporator)
 12VDC, .26A
 Replacement for Samsung

REFRIGERATION



Part No. **EAU61524007**
Motor (Evaporator)
 13V, 1.5W, 0.118A, 1-1/2" shaft
 Replacement for LG



Part No. **M245**
Motor (Evaporator)
 CW/CCW Rotation, 1-3/4" shaft
 Universal Replacement



Part No. **M249**
Motor (Evaporator)
 CW/CCW Rotation, Breakaway shaft
 Universal Replacement




Part No. **W10128551**
Motor (Evaporator)
 115V, 60 Hz, .14A, 1-3/8" shaft
 Replacement for Whirlpool



Part No. **W10188389**
Motor (Evaporator)
 120V, 60 Hz, .12A, 2950RPM, 7/8" shaft
 Replacement for Whirlpool



Part No. **W10189703**
Motor (Evaporator)
 120V, 60 Hz, .135A, 3000RPM, 1" shaft
 Replacement for Whirlpool



Part No. **W10822580**
Motor (Evaporator)
 12V, 3W, 1-1/2" shaft
 Replacement for Whirlpool



Part No. **WR60X162**
Motor (Evaporator)
 120V, 60 Hz, .135A, 3000RPM, 1-5/8" shaft
 Replacement for GE



Part No. **WR60X190**
Motor (Evaporator)
 120V, 60 Hz, .25A, 3000RPM, 1-3/8" shaft
 Replacement for GE



Part No. **WR60X203**
Motor (Evaporator)
 120V, 60 Hz, .21A, 3000RPM, 1-1/2" shaft
 Replacement for GE



Part No. **WR60X10074**
Motor (Evaporator)
 9.75VDC, 3.25W, 2-3/8" shaft
 Replacement for GE



Part No. **WR60X10141**
Motor (Evaporator)
 115V, 60 Hz, 3W, 1-5/8" shaft
 Replacement for GE




Part No. **WR60X10172**
Motor (Evaporator)
 115V, 60 Hz, .2A, 2800RPM, 2-5/8" shaft
 Replacement for GE



Part No. **WR60X10185**
Motor (Evaporator)
 9.75VDC, 3.25W, 2-3/8" shaft
 Replacement for GE



Part No. **WR60X10257**
Motor (Evaporator)
 115V, 60 Hz, 2.4W, 1-7/8" shaft
 Replacement for GE



Part No. **WR60X10277**
Motor (Evaporator)
 9.75VDC, 3.25W, 2-1/2" shaft
 Replacement for GE



Part No. **WR60X10307**
Motor (Evaporator)
 9.75VDC, 3.25W, 2-3/8" shaft
 Replacement for GE



Part No. **WR60X26085**
Motor (Evaporator)
 115V, 60 Hz, 1-1/4" shaft
 Replacement for GE



Part No. **WR60X23584**
Motor (Evaporator)
 115V, 60 Hz, 3.3W, 1-1/2" shaft
 Replacement for GE



Part No. **WR60X28783**
Motor (Evaporator)
 115V, 60 Hz, 3.3W, 1-3/8" shaft
 Replacement for GE



Part No. **WR60X31522**
Motor (Evaporator)
 115V, 60 Hz, 3.3W, 1-1/4" shaft
 Replacement for GE



Part No. **4680JB1026H**
Motor (Fan)
 115V, 60 Hz, 12A, 2-3/8" shaft
 Replacement for LG



Part No. **5209JA1044A**
Motor (Fan)
 Replacement for LG



Part No. **ABA72913413**
Motor (Fan)
 Replacement for LG

REFRIGERATION



Part No. **DA31-00070E**
Motor (Fan)
 Replacement for Samsung



Part No. **DA81-06013A**
Motor (Fan)
 Replacement for Samsung



Part No. **DA97-15765C**
Motor (Fan)
 Replacement for Samsung



Part No. **EAU64824401**
Motor (Fan)
 Replacement for LG



Part No. **EAU64824402**
Motor (Fan)
 Replacement for LG



Part No. **WR60X29099**
Motor (Fan)
 Replacement for GE



Part No. **M670**
Motor (Utility)
 120V, 60 Hz, .55A, 3000RPM, 1-1/4" shaft
 Universal Replacement



Part No. **2188829**
Overload/Relay
 Used on 22 cubic foot refrigerators
 Replacement for Whirlpool



Part No. **2188830**
Overload/Relay
 Used on 25 cubic foot refrigerators and larger
 Replacement for Whirlpool



Part No. **4387913**
Overload/Relay Kit
 Replacement for Whirlpool



Part No. **12555902**
Overload
 Replacement for Whirlpool



Part No. **WR07X10131**
Overload/PTCR Relay
 Replacement for GE



Part No. **WR08X22874**
Overload/Relay Kit
 Replacement for GE



Part No. **WR09X10106**
Overload/PTCR Relay
 Replacement for GE



Part No. **WR09X10107**
Overload/PTCR Relay
 Replacement for GE



Part No. **P410**
Power Start System
 120V, 1/4 and 1/3 HP



Part No. **P810**
Power Start System
 120V, 1/2 thru 1/5 HP



Part No. **IC102**
Relay



Part No. **ADH73150210**
Spun Copper Drier
 Replacement for LG



Part No. **D109**
Spun Copper Drier (Non-directional)
 1/4" inlet, 1/4" outlet, 3/4" diameter
 Recommended tonnage: (R-12)3/4 (R-22)1/2
 Economy with extended and fused ends




Part No. **D111**
Spun Copper Drier (Directional)
 1/4" inlet, Cap +1/4" outlet
 1" diameter, 3/16" process tube
 Recommended tonnage: (R-12)1-1/2 (R-22)3/4
 Heavy duty with Schrader to evacuate or charge
 the system, fused and scored ends



Part No. **D115**
Spun Copper Drier (Directional)
 1/4" inlet, Cap +1/4" outlet
 3/4" diameter, 3/16" process tube
 Recommended tonnage: (R-12)3/4 (R-22)1/2
 Economy with Schrader to evacuate or charge
 the system, fused and scored ends



Part No. **DA81-06007A**
Spun Copper Drier
 Replacement for Samsung




Part No. **8201786**
Start Device Kit
 Replacement for Whirlpool

REFRIGERATION



Part No. **W10197428**
Start Device
Replacement for Whirlpool



Part No. **W10448874**
Start Device
Replacement for Whirlpool



Part No. **W10613606**
Start Device
Replacement for Whirlpool




Part No. **41008**
Surge Protector




Part No. **240597203**
Temperature Sensor
Replacement for Electrolux



Part No. **6615JB2005H**
Temperature Sensor
Replacement for LG



Part No. **6615JB2005N**
Temperature Sensor
Replacement for LG



Part No. **6615JB2005R**
Temperature Sensor
Replacement for LG



Part No. **DA32-00006S**
Temperature Sensor
Replacement for Samsung



Part No. **DA32-00006W**
Temperature Sensor
Replacement for Samsung



Part No. **DA32-00011C**
Temperature Sensor
Replacement for Samsung




Part No. **DA32-00011D**
Temperature Sensor
Replacement for Samsung




Part No. **DA32-00029Q**
Temperature Sensor
Replacement for Samsung



Part No. **DA32-00033C**
Temperature Sensor
Replacement for Samsung



Part No. **DA32-10104N**
Temperature Sensor
Replacement for Samsung



Part No. **DA32-10105X**
Temperature Sensor
Replacement for Samsung



Part No. **DA32-10109W**
Temperature Sensor
Replacement for Samsung



Part No. **WR55X10025**
Temperature Sensor
Replacement for GE



Part No. **6500JB2001B**
Thermistor
Replacement for LG



Part No. **EBG60663205**
Thermistor
Replacement for LG



Part No. **W10316760**
Thermistor
Replacement for Whirlpool



Part No. **W10383615**
Thermistor
Replacement for Whirlpool



Part No. **W10384183**
Thermistor
Replacement for Whirlpool



Part No. **242046001**
Thermostat
Replacement for Electrolux

REFRIGERATION



Part No. **241685703**
Water Dispenser Actuator
Replacement for Electrolux



Part No. **4396508**
Water Filter
Replacement for Whirlpool



Part No. **5231JA2006B**
Water Filter
Replacement for LG



Part No. **ADQ36006102**
Water Filter
Replacement for LG



Part No. **DA29-00003G**
Water Filter
Replacement for Samsung



Part No. **DA29-00020B**
Water Filter
Replacement for Samsung



Part No. **SS08**
Water Filter
Replacement for GE



Part No. **SS10**
Water Filter
Replacement for Whirlpool #EDR2RXD1



Part No. **UKF8001**
Water Filter
Replacement for Whirlpool



Part No. **WF271**
Water Filter
Replacement for Whirlpool



Part No. **WFCB**
Water Filter
Replacement for Electrolux



Part No. **12544002**
Water Valve
Replacement for Whirlpool



Part No. **218832401**
Water Valve
Replacement for Electrolux



Part No. **218859701**
Water Valve
Replacement for Electrolux




Part No. **2315576**
Water Valve
Replacement for Whirlpool



Part No. **242252702**
Water Valve
Replacement for Electrolux



Part No. **5220JB2010A**
Water Valve
Replacement for LG



Part No. **5220JB2010T**
Water Valve
Replacement for LG



Part No. **5221JA2006D**
Water Valve
Replacement for LG



Part No. **61005273**
Water Valve
Replacement for Whirlpool



Part No. **67003753**
Water Valve
Replacement for Whirlpool



Part No. **67005154**
Water Valve
Replacement for Whirlpool



Part No. **67006531**
Water Valve
Replacement for Whirlpool



Part No. **AJU72992601**
Water Valve
Replacement for LG

REFRIGERATION



Part No. **AJU73753101**
Water Valve
 Replacement for LG



Part No. **DA62-02360B**
Water Valve
 Replacement for Samsung



Part No. **MJX41178908**
Water Valve
 Replacement for LG



Part No. **W10159839**
Water Valve
 Replacement for Whirlpool



Part No. **W10179146**
Water Valve
 Replacement for Whirlpool



Part No. **W10217917**
Water Valve
 Replacement for Whirlpool



Part No. **W10238100**
Water Valve
 Replacement for Whirlpool



Part No. **W10258562**
Water Valve
 Replacement for Whirlpool



Part No. **W10279866**
Water Valve
 Replacement for Whirlpool



Part No. **W10279909**
Water Valve
 Replacement for Whirlpool



Part No. **W10312696**
Water Valve
 Replacement for Whirlpool



Part No. **W10341320**
Water Valve
 Replacement for Whirlpool



Part No. **W10341329**
Water Valve
Replacement for Whirlpool



Part No. **W10394076**
Water Valve
Replacement for Whirlpool



Part No. **W10408179**
Water Valve
Replacement for Whirlpool



Part No. **W10420083**
Water Valve
Replacement for Whirlpool



Part No. **W10498976**
Water Valve
Replacement for Whirlpool



Part No. **W10498990**
Water Valve
Replacement for Whirlpool



Part No. **W10822681**
Water Valve
Replacement for Whirlpool



Part No. **W10853654**
Water Valve
Replacement for Whirlpool



Part No. **W10865826**
Water Valve
Replacement for Whirlpool



Part No. **W10881366**
Water Valve
Replacement for Whirlpool



Part No. **W11043013**
Water Valve
Replacement for Whirlpool



Part No. **WR57X10033**
Water Valve
Replacement for GE


REFRIGERATION



Part No. **WR57X10051**
Water Valve
Replacement for GE



Part No. **WR57X10086**
Water Valve
Replacement for GE



Part No. **WR71X2086**
Wire Rack
Replacement for GE



Part No. **W10006355**
Actuator
Replacement for Whirlpool




Part No. **W10913953**
Actuator
Replacement for Whirlpool



Part No. **W10352973**
Actuator (Dispenser)
Replacement for Whirlpool



Part No. **285811**
Agitate Cam Kit
Replacement for Whirlpool



Part No. **WH49X10042**
Agitate Coupling
Replacement for GE



Part No. **80040**
Agitate Dogs (4pk)
Replacement for Whirlpool



Part No. **4413ER1003B**
Assembly Rotor
Replacement for LG



Part No. **AHL72914402**
Assembly Rotor
Replacement for LG




Part No. **4417EA1002K**
Assembly Stator
Replacement for LG




Part No. **4417EA1002Y**
Assembly Stator
Replacement for LG



Part No. **285792**
Basket Drive
Replacement for Whirlpool



Part No. **MAP61913708**
Bearing
2-7/8" diameter
Replacement for LG



Part No. **MAP61913727**

Bearing

2-1/2" diameter
Replacement for LG



Part No. **W10435302**

Bearing

Replacement for Whirlpool



Part No. **211124**

Belt


Replacement for Whirlpool



Part No. **211125**

Belt

Replacement for Whirlpool



Part No. **8540101**

Belt

Replacement for Whirlpool



Part No. **21352320**

Belt

Replacement for Whirlpool



Part No. **22003483**

Belt

Replacement for Whirlpool



Part No. **27001006**

Belt

Replacement for Whirlpool



Part No. **131686100**

Belt

Replacement for Electrolux



Part No. **W10006384**

Belt

Replacement for Whirlpool



Part No. **W10260319**

Belt

Replacement for Whirlpool



Part No. **W11239857**

Belt

Replacement for Whirlpool



Part No. **WH01X10302**
Belt
 Replacement for GE



Part No. **WH08X10024**
Belt
 Replacement for GE




Part No. **WH08X10050**
Belt
 Replacement for GE



Part No. **12112425**
Belt Kit
 Replacement for Whirlpool



Part No. **WH1X2727**
Bungee Cord
 Replacement for GE



Part No. **00154740**
Carbon Brush (2pk)
 Replacement for Bosch



Part No. **285785**
Clutch Assembly
 Replacement for Whirlpool



Part No. **285753**
Coupler (Drive)
 Replacement for Whirlpool



Part No. **285753A**
Coupler (Drive)
 Has metal inserts
 Replacement for Whirlpool



Part No. **285852**
Coupler (Heavy Duty)
 Replacement for Whirlpool



Part No. **WH01X10261**
Damper Pin
 Replacement for GE



Part No. **426862P**
Diverter Valve
 Replacement for Fisher Paykel



Part No. **00772658**

Door Boot

Replacement for Bosch



Part No. **4986ER0004G**

Door Boot

Replacement for LG



Part No. **706276**

Door Boot

Replacement for Bosch



Part No. **8182119**

Door Boot

Replacement for Whirlpool



Part No. **DC64-00802AB**

Door Boot

Replacement for Samsung



Part No. **DC97-19755A**

Door Boot

Replacement for Samsung



Part No. **MDS47123605**

Door Boot

Replacement for LG



Part No. **MDS47123608**

Door Boot

Replacement for LG



Part No. **4775ER2002A**

Door Hinge


Replacement for LG



Part No. **AGM73610701**

Door Plunger

Replacement for LG



Part No. **W10528947**

Drive Hub

Replacement for Whirlpool



Part No. **W10820039**

Drive Hub Kit

Replacement for Whirlpool



Part No. **W10721967**
Drive Splutch Kit
 Replacement for Whirlpool



Part No. **W10110225**
Flowmeter
 Replacement for Whirlpool



Part No. **8181846**
Handle
 Replacement for Whirlpool



Part No. **3804FF**
Hose (Fill)
 4 ft. female x female



Part No. **3805FF**
Hose (Fill)
 5 ft. female x female



Part No. **3806FF**
Hose (Fill)
 6 ft. female x female



Part No. **3806MF**
Hose (Fill)
 6 ft. male x female



Part No. **3815FF**
Hose (Fill)
 15 ft. female x female



Part No. **4738ER1002A**
Hose
 Replacement for LG



Part No. **WDH6FT**
Hose (Drain)
 6 ft.



Part No. **WH1X2754**
Knob
 1-7/8" diameter
 Replacement for GE



Part No. **WH01X10310**
Knob
 2" diameter, 1/2" ext. shaft
 Replacement for GE



Part No. **WH01X10460**
Knob
1-7/8" diameter, 1/8" ext. shaft
Replacement for GE



Part No. **131763202**
Latch (Lid)
Replacement for Electrolux



Part No. **W10619844**
Latch (Lid)
Replacement for Whirlpool



Part No. **W11307244**
Latch
Replacement for Whirlpool



Part No. **W10404050**
Latch Assembly
Replacement for Whirlpool



Part No. **49621**
Leveling Leg
Replacement for Whirlpool



Part No. **285671**
Lid Switch
Replacement for Whirlpool



Part No. **3355806**
Lid Switch
Replacement for Whirlpool



Part No. **3949238**
Lid Switch
Replacement for Whirlpool



Part No. **3949247**
Lid Switch
Replacement for Whirlpool



Part No. **8318084**
Lid Switch
Replacement for Whirlpool



Part No. **EBF61215202**
Lid Switch
Replacement for LG



Part No. **EBF61674802**

Lid Switch

Replacement for LG



Part No. **W10820036**

Lid Switch

Replacement for Whirlpool



Part No. **WH12X10334**

Lid Switch

Replacement for GE



Part No. **3921FZ3147Q**

Lint Filter (2 pack)

Replacement for LG



Part No. **203504**

Lock (Door)


Replacement for Alliance



Part No. **802317P**

Lock (Door)

Replacement for Speedqueen



Part No. **134936800**

Lock (Door)

Replacement for Electrolux



Part No. **5304505231**

Lock (Door)

Replacement for Electrolux



Part No. **DC34-00025E**

Lock (Door)

Replacement for Samsung



Part No. **EBF49827801**

Lock (Door)

Replacement for LG



Part No. **EBF61315802**

Lock (Door)

Replacement for LG



Part No. **DC34-00024B**

Lock (Door)

Replacement for Samsung



Part No. **W10192995**

Lock (Door)

Replacement for Whirlpool



Part No. **WH10X10006**

Lock (Door)


Replacement for GE



Part No. **204698**

Lock (Lid)

Replacement for Alliance



Part No. **137353302**

Lock (Lid)

Replacement for Electrolux



Part No. **WH44X10288**

Lock (Lid)

Replacement for GE



Part No. **W10804664**

Motor Run Capacitor

Replacement for Whirlpool



Part No. **W10804665**

Motor Run Capacitor

Replacement for Whirlpool



Part No. **KP-2**

Pliers (Hose Clamp)

Service tool for double ring wire clamps
Plier locks clamp in jaw



Part No. **THP-1**

Pliers (Hose)

8-3/4" length
Great for washers with indented water valves



Part No. **201609P**

Pressure Switch

Replacement for Speedqueen



Part No. **202937**

Pressure Switch

Replacement for Speedqueen



Part No. **134762010**

Pressure Switch

Replacement for Electrolux



Part No. **DC96-01703B**
Pressure Switch
Replacement for Samsung



Part No. **DC96-01703H**
Pressure Switch
Replacement for Samsung



Part No. **W10268911**
Pressure Switch
Replacement for Whirlpool




Part No. **W11316246**
Pressure Switch
Replacement for Whirlpool



Part No. **WH12X10412**
Pressure Switch
Replacement for GE



Part No. **WH12X10476**
Pressure Switch
Replacement for GE



Part No. **WH12X10479**
Pressure Switch
Replacement for GE



Part No. **25001052**
Pump (Drain)
Replacement for Whirlpool



Part No. **34001098**
Pump (Drain)
Replacement for Whirlpool



Part No. **34001320**
Pump (Drain)
Replacement for Whirlpool



Part No. **34001340**
Pump (Drain)
Replacement for Whirlpool



Part No. **137311900**
Pump (Drain)
Replacement for Electrolux



Part No. **5304524452**
Pump (Drain)
 Replacement for Electrolux



Part No. **DC31-00054A**
Pump (Drain)
 Replacement for Samsung



Part No. **DC31-00054D**
Pump (Drain)
 Replacement for Samsung



Part No. **DC96-01414A**
Pump (Drain)
 Replacement for Samsung



Part No. **DC96-01700A**
Pump (Drain)
 Replacement for Samsung



Part No. **EAU61383503**
Pump (Drain)
 Replacement for LG



Part No. **W10409079**
Pump (Drain)
 Replacement for Whirlpool



Part No. **W10465252**
Pump (Drain)
 Replacement for Whirlpool



Part No. **W10661045**
Pump (Drain)
 Replacement for Whirlpool



Part No. **W10876600**
Pump (Drain)
 Replacement for Whirlpool



Part No. **W10919003**
Pump (Drain)
 Replacement for Whirlpool



Part No. **WH23X26206**
Pump (Drain)
 Replacement for GE



Part No. **4681EA2001T**
Pump
Replacement for LG



Part No. **4681EA2002H**
Pump
Replacement for LG



Part No. **280187**
Pump
Replacement for Whirlpool



Part No. **3363394**
Pump
Replacement for Whirlpool



Part No. **21001906**
Pump
Replacement for Whirlpool



Part No. **137108000**
Pump
Replacement for Electrolux



Part No. **137221600**
Pump
Replacement for Electrolux



Part No. **137240800**
Pump
Replacement for Electrolux



Part No. **5304514769**
Pump
Replacement for Electrolux



Part No. **W10276397**
Pump
Replacement for Whirlpool



Part No. **W10391443**
Pump
Replacement for Whirlpool



Part No. **W10425238**
Pump
Replacement for Whirlpool



Part No. **W10536347**

Pump

Replacement for Whirlpool



Part No. **W10581874**

Pump

Replacement for Whirlpool



Part No. **W10730972**

Pump

Replacement for Whirlpool



Part No. **W11458345**

Pump

Replacement for Whirlpool



Part No. **WH23X10028**

Pump

Replacement for GE



Part No. **WH23X10030**

Pump

Replacement for GE



Part No. **647920**

Pump Filter

Replacement for Bosch



Part No. **DC31-00181C**

Pump Motor


Replacement for Samsung



Part No. **EAU62263306**

Pump Motor

Replacement for LG



Part No. **DC31-00098A**

Sensor

Replacement for Samsung



Part No. **6501KW2002A**

Sensor (Motor)

Replacement for LG



Part No. **DC93-00278B**

Sensor (Vibration)

Replacement for Samsung



Part No. **6501EA1001R**
Sensor Switch Assembly
 Replacement for LG



Part No. **00642112**
Shock Absorber
 Replacement for Bosch



Part No. **00742719**
Shock Absorber
 Replacement for Bosch



Part No. **383EER3001G**
Shock Absorber
 Replacement for LG



Part No. **383EER3001V**
Shock Absorber
 Replacement for LG



Part No. **8182703**
Shock Absorber
 Replacement for Whirlpool



Part No. **137412601**
Shock Absorber
 Replacement for Electrolux



Part No. **137412701**
Shock Absorber
 Replacement for Electrolux



Part No. **5304485917**
Shock Absorber
 Replacement for Electrolux



Part No. **DC66-00343A**
Shock Absorber
 Replacement for Samsung



Part No. **DC66-00470A**
Shock Absorber
 Replacement for Samsung



Part No. **DC66-00470B**
Shock Absorber
 Replacement for Samsung



Part No. **W10822553**
Shock Absorber
Replacement for Whirlpool



Part No. **WH01X10343**
Shock Absorber
Replacement for GE



Part No. **WH01X10343KIT**
Shock Absorber (4 pack)
Replacement for GE



Part No. **WH01X10727**
Shock Absorber
Replacement for GE



Part No. **WH01X20826**
Shock Absorber
Replacement for GE



Part No. **W10869845**
Stacking Kit
Replacement for Whirlpool



Part No. **131763310**
Striker
Replacement for Electrolux



Part No. **DC97-05280S**
Suspension Rod
Replacement for Samsung




Part No. **DC97-05280W**
Suspension Rod
Replacement for Samsung



Part No. **DC97-16350C**
Suspension Rod
Replacement for Samsung




Part No. **DC97-16350E**
Suspension Rod
Replacement for Samsung




Part No. **W10247710**
Suspension Kit
Replacement for Whirlpool



Part No. **W10780045**
Suspension Kit
Replacement for Whirlpool




Part No. **W10780048**
Suspension Kit
Replacement for Whirlpool



Part No. **W10820048**
Suspension Kit
Replacement for Whirlpool



Part No. **4970FR2084Z**
Suspension Spring
Replacement for LG



Part No. **W10448876**
Switch
Replacement for Whirlpool



Part No. **DC90-10128N**
Thermistor
Replacement for Samsung



Part No. **37927P**
Timer
Replacement for Speedqueen



Part No. **8541110**
Timer
Replacement for Whirlpool



Part No. **8557393**
Timer
Replacement for Whirlpool



Part No. **8577356**
Timer
Replacement for Whirlpool



Part No. **W10111389**
Timer
Replacement for Whirlpool



Part No. **W10199989**
Timer
Replacement for Whirlpool



Part No. **383727**
Tub Grommet
Replacement for Whirlpool



Part No. **TB123A**
Tub Nut Wrench
Removes tub nut from washing machines



Part No. **WM0612N**
Washer Magic
(Sold in 6PK case ONLY)
Removes lime scale, soap scum & iron stains
Safe for plumbing & septic systems



Part No. **W10339251**
Water Level Switch
Replacement for Whirlpool




Part No. **134211400**
Water Valve
Replacement for Electrolux



Part No. **134371220**
Water Valve
Replacement for Electrolux



Part No. **134637810**
Water Valve
Replacement for Electrolux



Part No. **134959340**
Water Valve
Replacement for Electrolux



Part No. **201468P**
Water Valve
Replacement for Speedqueen



Part No. **202395P**
Water Valve
Replacement for Speedqueen



Part No. **343**
Water Valve
Universal Replacement



Part No. **3979346**
Water Valve
Replacement for Whirlpool



Part No. **422244**
Water Valve
 Replacement for Bosch



Part No. **422245**
Water Valve
 Replacement for Bosch



Part No. **5220FR2006H**
Water Valve
 Replacement for LG



Part No. **5220FR2008C**
Water Valve
 Replacement for LG



Part No. **5220FR2008F**
Water Valve
 Replacement for LG



Part No. **5220FR2075C**
Water Valve
 Replacement for LG



Part No. **5221ER1003A**
Water Valve
 Replacement for LG



Part No. **525**
Water Valve
 Universal Replacement



Part No. **8181694**
Water Valve
 Replacement for Whirlpool



Part No. **8182862**
Water Valve
 Replacement for Whirlpool



Part No. **8540751**
Water Valve
 Replacement for Whirlpool



Part No. **8578341**
Water Valve
 Replacement for Whirlpool



Part No. **AJU75152601**
Water Valve
Replacement for LG



Part No. **DC62-00142G**
Water Valve
Replacement for Samsung



Part No. **DC62-00214M**
Water Valve
Replacement for Samsung



Part No. **DC62-30312J**
Water Valve
Replacement for Samsung



Part No. **DC62-30314K**
Water Valve
Replacement for Samsung



Part No. **DC97-15459D**
Water Valve
Replacement for Samsung



Part No. **DC97-15459G**
Water Valve
Replacement for Samsung



Part No. **DC97-15459H**
Water Valve
Replacement for Samsung



Part No. **W10144820**
Water Valve
Replacement for Whirlpool



Part No. **W10175893**
Water Valve
Replacement for Whirlpool



Part No. **W10212596**
Water Valve
Replacement for Whirlpool



Part No. **W10212598**
Water Valve
Replacement for Whirlpool



Part No. **W10247306**
Water Valve
Replacement for Whirlpool



Part No. **W10289387**
Water Valve
Replacement for Whirlpool



Part No. **W10326913**
Water Valve
Replacement for Whirlpool



Part No. **W10599356**
Water Valve
Replacement for Whirlpool



Part No. **W10683603**
Water Valve
Replacement for Whirlpool



Part No. **W10853723**
Water Valve
Replacement for Whirlpool



Part No. **W11096267**
Water Valve
Replacement for Whirlpool



Part No. **W11168740**
Water Valve
Replacement for Whirlpool



Part No. **W11168743**
Water Valve
Replacement for Whirlpool




Part No. **W11220230**
Water Valve
Replacement for Whirlpool



Part No. **WH13X10024**
Water Valve
Replacement for GE



Part No. **WH13X10025**
Water Valve
Replacement for GE



Part No. **WH13X10026**
Water Valve
Replacement for GE



Part No. **WH13X10027**
Water Valve
Replacement for GE



Part No. **WH13X10029**
Water Valve
Replacement for GE



Part No. **WH13X10037**
Water Valve
Replacement for GE



Part No. **WH13X10048**
Water Valve
Replacement for GE



Part No. **WH13X22314**
Water Valve
Replacement for GE



Part No. **WH13X22720**
Water Valve
Replacement for GE



Part No. **WH13X25296**
Water Valve
Replacement for GE



Part No. **WH13X26535**
Water Valve
Replacement for GE



Part No. **WH13X27314**
Water Valve
Replacement for GE

INDEX

00154740.....	93	69W43.....	56	5318EL3001A.....	47	312959.....	41
00167082.....	35	87F16.....	57	5817S0007.....	23	318984-753.....	58
00263096.....	33	98M87.....	56	6286W.....	14	330031.....	29
00436440.....	35	98QBPO300.....	62	6500JB2001B.....	85	338906.....	45
00480317.....	35	98QBPO302.....	62	6501EA1001R.....	103	339392.....	49
00494772.....	33	98QBPO303.....	62	6501KW2002A.....	102	341241.....	41
00611332.....	35	197.....	52	6513S0001.....	23	349241.....	51
00611666.....	37	343.....	106	6520S0201.....	23	349241T.....	51
00618605.....	32	383EER3001G.....	103	6540S0001.....	23	349639.....	49
00620774.....	35	383EER3001V.....	103	6544S0001.....	23	383727.....	106
00628334.....	39	525.....	107	6545S0001.....	23	422244.....	107
00631200.....	35	944KIT.....	58	6547S0001.....	23	422245.....	107
00642112.....	103	947KIT.....	58	6549S0001.....	23	425458.....	39
00645208.....	32	1003.....	57	6600JB1010A.....	74	426862P.....	93
00648255.....	21	1090.....	56	6600JB3007E.....	73	482469.....	78
00652184.....	48	1126.....	22	6600JB3007K.....	74	482731.....	78
00668114.....	33	1153KIT.....	43	6602-001655.....	41	490467.....	32
00742719.....	103	1398.....	6	6615JB2005H.....	84	607335.....	39
00754866.....	33	1408.....	56	6615JB2005N.....	84	611475.....	37
00754873.....	33	1409.....	57	6615JB2005R.....	84	622058.....	39
00772658.....	94	1438.....	22	6700S0011.....	30	642239.....	36
0130F00010KIT.....	56	1440.....	22	6930W1A003X.....	30	644424.....	9
02532625000.....	56	1801M58.....	6	6931EL3001E.....	54	647920.....	102
3-60336-001.....	77	1801M59.....	6	6931EL3001F.....	54	661566.....	39
6-3700340.....	46	1802A206.....	22	6931EL3003C.....	54	661658.....	36
10C7.....	2	1842A57.....	30	6931EL3003D.....	54	675813.....	39
10QBPO228.....	60	1999.....	22	6931EL3004B.....	54	691366.....	46
10QBPO229.....	60	3412A004-19.....	6	7212P043-60.....	19	694089.....	42
10QBPO230.....	61	3700KIT2.....	50	7403P23960.....	12	694674.....	54
10QBPO231.....	61	3804FF.....	95	7737P245-60.....	14	706276.....	94
10QBPO232.....	61	3805FF.....	95	8504.....	9	802317P.....	97
10QBPO234.....	61	3806FF.....	95	18806.....	74	819043.....	75
10QBPO235.....	61	3806MF.....	95	37927P.....	105	902894.....	34
10QBPI000.....	61	3815FF.....	95	41008.....	84	903758.....	57
10QBPI003.....	61	3920DD3005A.....	33	49621.....	96	1013833.....	58
10QBPI004.....	61	3921FZ3147Q.....	97	56120.....	22	2159057.....	70
10QBPI006.....	62	4400EL2001A.....	41	61927.....	44	2159061.....	70
11QBPO236.....	60	4413ER1003B.....	91	80040.....	91	2159327.....	70
11QBPUUNIV.....	60	4417EA1002K.....	91	110222.....	45	2163777.....	74
13QBP21090.....	59	4417EA1002Y.....	91	165314.....	37	2169142.....	74
13QBP21095.....	59	4560EL3001A.....	46	189324.....	10	2183141.....	74
13QBP21100.....	59	4561EL3002A.....	46	201468P.....	106	2183400.....	69
13QBP21105.....	59	4581EL2002C.....	51	201609P.....	98	2188436A.....	70
14QBP20CFB.....	59	4581EL2002H.....	51	202395P.....	106	2188448A.....	70
14QBP20CSB.....	59	4581KIT.....	50	202937.....	98	2188462A.....	71
14Y70.....	57	4680JB1026H.....	81	203504.....	97	2188829.....	82
18G89.....	56	4681EA2001T.....	101	204698.....	98	2188830.....	82
25QBP3779.....	60	4681EA2002H.....	101	211124.....	92	2188874.....	78
25QBP3780.....	60	4681ED1004B.....	35	211125.....	92	2198202.....	64
25QBP3784.....	60	4681JB1027C.....	77	279393.....	50	2200859.....	64
25QBP3785.....	60	4681JB1029B.....	78	279408.....	44	2212363.....	76
26QBP0213.....	59	4681JB1029D.....	77	279570.....	42	2252130.....	76
26QBP0264.....	59	4681JB1029H.....	78	279570M.....	42	2262080.....	71
26QBP0930.....	59	4738ER1002A.....	95	279640.....	46	2263749.....	66
26QBP3236.....	59	4750.....	60	279735.....	44	2304099.....	65
26QBP4076.....	59	4775ER2002A.....	94	279769.....	52	2315547.....	76
26QBP4093.....	59	4970FR2084Z.....	105	279816.....	52	2315549.....	78
28QBP0491.....	62	4986ER0004G.....	94	279838.....	44	2315576.....	87
28QBP0495.....	62	5209JA1044A.....	81	279973.....	52	2319264T.....	71
28QBP0496.....	62	5220FR2006H.....	107	280148.....	52	2319265T.....	71
28QBP0497.....	62	5220FR2008C.....	107	280187.....	101	2319266T.....	71
28QBP0499.....	62	5220FR2008F.....	107	285671.....	96	2322580.....	76
30QBP1848.....	63	5220FR2075C.....	107	285753.....	93	2323198.....	66
30QBP4185.....	63	5220JB2010A.....	87	285753A.....	93	3148952.....	11
34FHT.....	35	5220JB2010T.....	87	285785.....	93	3148953.....	11
40A15.....	2	5221DD1001E.....	40	285792.....	91	3149400.....	11
40QBP1012.....	63	5221ER1003A.....	107	285811.....	91	3149404.....	12
40T61/2.....	2	5221JA2006D.....	87	285852.....	93	3181304.....	14
52W29.....	56	5231EL1003B.....	48	303373K.....	51	3196803.....	30
53-0918.....	49	5231JA2006B.....	86	303404.....	44	3203459.....	23
60J00.....	57	5301EL1001G.....	44	303836.....	42	3204267.....	53

INDEX

3355806.....	96	9759242.....	29	134719300.....	41	316039003.....	7
3363394.....	101	9759243.....	30	134762010.....	98	316067902.....	20
3387134.....	53	10006917.....	32	134792700.....	45	316091706.....	22
3387747.....	44	10359708Q.....	71	134793511.....	46	316102303.....	17
3390719.....	52	12001541.....	51	134844470.....	48	316103802.....	6
3392519.....	52	12001596.....	24	134886700.....	48	316215900.....	30
3394652.....	41	12001655.....	21	134936800.....	97	316215901.....	30
3399849.....	53	12001656.....	21	134959340.....	106	316217002.....	21
3406105.....	42	12001676.....	29	137032600.....	53	316220000.....	15
3406107.....	43	12002744.....	78	137051400.....	41	316220008.....	15
3406108.....	43	12004485.....	37	137108000.....	101	316220009.....	15
3949238.....	96	12112425.....	93	137114000.....	45	316233902.....	21
3949247.....	96	12544002.....	86	137221600.....	101	316238201.....	12
3977767.....	54	12550109Q.....	71	137240800.....	101	316238202.....	12
3979346.....	106	12550111Q.....	71	137292700.....	41	316239700.....	19
4334809.....	20	12550115Q.....	71	137311900.....	99	316270200.....	7
4387490.....	67	12550116Q.....	71	137353302.....	98	316270201.....	7
4387503.....	67	12555902.....	82	137412601.....	103	316282000.....	27
4387913.....	82	20165703S.....	57	137412701.....	103	316353104.....	15
4388736.....	64	21001906.....	101	137513300KIT.....	43	316405000.....	19
4389102.....	76	21352320.....	92	137539200.....	53	316436000.....	12
4389144.....	78	22003483.....	92	137544800.....	47	316436001.....	12
4391960.....	44	25001052.....	99	154430501.....	38	316489403.....	9
4392065.....	50	27001006.....	92	154568001.....	38	316496201.....	20
4392067.....	50	31001556.....	47	154578801.....	32	316543907.....	15
4396508.....	86	33001003.....	50	154579101.....	33	316564509.....	15
4452395.....	63	33001807.....	45	154580301.....	36	318099104.....	15
4452396.....	63	33001808.....	50	154637401.....	40	318601604.....	27
5500200.....	12	33002032.....	41	154701001.....	38	807004702.....	12
5500202M.....	12	33002970.....	50	154825001.....	33	807047901.....	40
5502404.....	12	34001098.....	99	154827601.....	34	808602601.....	79
6610341.....	23	34001320.....	99	215366002.....	70	808608801.....	24
8181694.....	107	34001340.....	99	215846602.....	69	809006501.....	38
8181846.....	95	37001042.....	51	218730603.....	72	5300158289.....	79
8182119.....	94	37001287.....	46	218832401.....	87	5300622032.....	45
8182703.....	103	37001298.....	43	218859701.....	87	5300622034.....	45
8182862.....	107	40111201.....	41	218969902.....	67	5303281153.....	43
8193762.....	39	40113801.....	53	240338001.....	70	5303283286.....	45
8194001.....	35	61001846.....	66	240369701.....	78	5303918202.....	67
8201756.....	70	61004003.....	71	240457701.....	70	5303918214.....	68
8201786.....	83	61004008.....	71	240597203.....	84	5303918277.....	75
8268383.....	32	61004888.....	78	241509402.....	78	5303918344.....	75
8268743.....	37	61005273.....	87	241537103.....	64	5303918549.....	79
8269145.....	32	61005935.....	78	241685703.....	86	5303937139.....	43
8270020.....	33	67003426.....	67	241705102.....	69	5303937182.....	44
8273106.....	14	67003753.....	87	241798224.....	75	5304404821.....	65
8273992.....	27	67005451.....	87	241854301.....	79	5304421256.....	65
8273993.....	27	67006531.....	87	241872501.....	72	5304464438.....	64
8300802.....	29	71001641.....	14	241872502.....	72	5304485917.....	103
8318084.....	96	71001841.....	19	241872503.....	72	5304504077.....	39
8523793.....	11	74002390.....	30	241872504.....	72	5304505231.....	97
8531669.....	40	74005019.....	30	241872505.....	72	5304506469.....	75
8531964.....	48	74005890.....	11	241872509.....	72	5304506471.....	75
8540101.....	92	74007733.....	14	241872510.....	72	5304506516.....	38
8540751.....	107	74010141.....	20	241872512.....	72	5304507386.....	15
8541110.....	105	74010205.....	15	241872513.....	72	5304509457.....	62
8544742.....	41	74010839.....	15	241920106.....	74	5304509929.....	16
8544771.....	44	74011260.....	15	241993001.....	65	5304513033.....	65
8547157.....	41	74011287.....	15	241993101.....	65	5304514769.....	101
8547174.....	46	97012038.....	19	242044020.....	66	5304516159.....	26
8557393.....	105	97012248.....	19	242044113.....	66	5304516160.....	26
8557403.....	54	98003984.....	30	242046001.....	85	5304516871.....	49
8557884.....	49	131686100.....	92	242077705.....	79	5304517203.....	38
8561996.....	37	131763202.....	96	242219204.....	79	5304518034.....	69
8565925KIT.....	38	131763310.....	104	242221501.....	77	5304518927.....	38
8572270.....	49	131863007.....	46	242252702.....	87	5304519906.....	37
8577274.....	53	134120900.....	53	243297606.....	75	5304524452.....	100
8577356.....	105	134211400.....	106	297250000.....	79	5304525044.....	39
8578341.....	107	134371220.....	106	316031501.....	23	A000443305.....	36
9755542.....	29	134637810.....	106	316032411.....	30	A00126401.....	36
9758079.....	11	134715900.....	51	316039002.....	6	A00126501.....	36

INDEX

ABA72913413.....	81	DA47-00322J.....	66	DD62-00084A.....	40	LH680005.....	58
ADH73150210.....	83	DA47-00424A.....	66	DD81-02132A.....	33	LH680014.....	56
ADQ36006102.....	86	DA47-00424B.....	67	DD82-01121A.....	38	M245.....	80
ADQ56656401.....	49	DA47-00424L.....	67	DE382.....	42	M249.....	80
AEQ72909603.....	75	DA47-00434A.....	67	DE47-20034A.....	62	M550.....	19
AEQ73209906.....	75	DA62-02360B.....	88	DE47-20060A.....	63	M670.....	82
AGB73093001.....	38	DA81-06007A.....	83	DE91-70063D.....	60	MAP61913708.....	91
AGM73610701.....	94	DA81-06013A.....	82	DG31-00005A.....	18	MAP61913727.....	92
AGM76209501.....	32	DA97-04049E.....	74	DG32-00002B.....	21	MCU61861001.....	32
AHL72914402.....	91	DA97-05253B.....	72	DG32-00004C.....	21	MDS47123605.....	94
AJU72992601.....	87	DA97-05557Y.....	73	DG44-01002A.....	12	MDS47123608.....	94
AJU73753101.....	88	DA97-15765C.....	82	DG44-01008A.....	12	MEE36593202.....	4
AJU75152601.....	108	DB6GE1.....	7	DG44-01009A.....	13	MEE61841401.....	10
B0750.....	2	DB6GE2.....	8	DG47-00038B.....	4	MEE62306504.....	4
B1094.....	3	DB6WH.....	8	DG47-00065A.....	27	MEE62385201.....	27
B1117.....	3	DB8GE1.....	8	DG47-00066A.....	27	MEF62782201.....	46
B1401018S.....	57	DB8GE2.....	8	DG47-00067A.....	27	MJX41178908.....	88
B1551.....	5	DB8WH.....	8	DG62-00067A.....	7	MLT45.....	68
B1859005.....	57	DBU6.....	8	DG62-00070A.....	7	MLT50.....	68
B2200.....	3	DBU6P.....	8	DG62-00074C.....	7	MLT55.....	68
B2395.....	3	DBU6P1.....	8	DG62-00076B.....	7	MLT60.....	68
B3200.....	5	DBU8.....	8	DG62-00111A.....	7	NEX200828.....	9
B3301.....	5	DBU8P.....	8	DG94-00449A.....	22	P410.....	83
B3800.....	3	DBU8P1.....	8	DG94-00520A.....	9	P810.....	83
B4107.....	3	DC31-00054A.....	100	DG94-01012A.....	10	PA020047.....	24
B5002.....	3	DC31-00054D.....	100	DG96-00297A.....	24	PR1.....	22
B5103.....	3	DC31-00055G.....	50	DM06N.....	32	PR2.....	22
B5900.....	3	DC31-00098A.....	102	DVC202PK.....	48	PR4.....	22
B68C.....	42	DC31-00181C.....	102	DWDH78.....	33	PU410.....	75
B7019.....	3	DC32-00007A.....	53	EAFCBF.....	64	R117.....	29
B7340.....	5	DC34-00024B.....	97	EAU59551204.....	77	RS65D12.....	27
B7646.....	3	DC34-00025E.....	97	EAU61383503.....	100	RS85D20.....	27
B775.....	2	DC47-00016A.....	53	EAU61524007.....	80	RS975D25.....	28
B777.....	2	DC47-00017A.....	54	EAU61865301.....	18	S218.....	26
B778.....	2	DC47-00018A.....	54	EAU62043403.....	36	S219.....	26
B779.....	5	DC47-00019A.....	45	EAU62263306.....	102	S30M1.....	25
B790.....	2	DC47-00022A.....	47	EAU62343001.....	18	S30M2.....	25
B837.....	2	DC62-00142G.....	108	EAU64824401.....	82	S348.....	26
B8541.....	3	DC62-00214M.....	108	EAU64824402.....	82	S354.....	26
B856.....	2	DC62-30312J.....	108	EBF49827801.....	97	S359.....	26
D109.....	83	DC62-30314K.....	108	EBF61215202.....	96	S36Y12.....	25
D111.....	83	DC64-00802AB.....	94	EBF61315802.....	97	S46D15.....	25
D115.....	83	DC64-00828A.....	43	EBF61674802.....	97	S46Y12.....	25
D510184P.....	47	DC66-00343A.....	103	EBG60663205.....	85	S46Y15.....	25
D7813010.....	76	DC66-00470A.....	103	EBR71326804.....	64	S48D21.....	25
DA29-00003G.....	86	DC66-00470B.....	103	EXT12FT.....	48	S48Y21.....	25
DA29-00020B.....	86	DC90-10128N.....	105	FLTR012.....	9	S58D21.....	25
DA31-00070E.....	82	DC93-00278B.....	102	GEIM.....	75	S58D26.....	25
DA31-00146B.....	79	DC93-00634A.....	46	GP1.....	69	S58Y21.....	25
DA31-00146E.....	79	DC96-00887C.....	54	GP11.....	69	S58Y26.....	26
DA31-00146H.....	79	DC96-01414A.....	100	GR403.....	10	SEN01114.....	56
DA31-00146J.....	79	DC96-01700A.....	100	H-301.....	57	SHUBEE.....	58
DA31-00334A.....	79	DC96-01703B.....	99	H-316.....	57	SKK-7A.....	52
DA32-00006S.....	84	DC96-01703H.....	99	IC102.....	83	SS08.....	86
DA32-00006W.....	84	DC97-05280S.....	104	IG0001.....	10	SS10.....	86
DA32-00011C.....	84	DC97-05280W.....	104	IG10016.....	10	TB123A.....	106
DA32-00011D.....	84	DC97-14486A.....	45	IG101.....	57	THP-1.....	98
DA32-00029Q.....	85	DC97-15459D.....	108	IG21.....	10	TR6GE.....	8
DA32-00033C.....	85	DC97-15459G.....	108	IG35.....	10	TR8GE.....	9
DA32-10104N.....	85	DC97-15459H.....	108	IG5652.....	10	UDI.....	47
DA32-10105X.....	85	DC97-16350C.....	104	IG9400.....	10	UKF8001.....	86
DA32-10109W.....	85	DC97-16350E.....	104	IG9998.....	10	W10006355.....	91
DA34-00041B.....	74	DC97-16782A.....	51	IMKR8.....	76	W10006384.....	92
DA41-00676J.....	64	DC97-19755A.....	94	KN001.....	17	W10110225.....	95
DA47-00243K.....	68	DC97KIT4.....	50	KN002.....	17	W10110486.....	24
DA47-00244B.....	66	DD31-00005A.....	36	KP-2.....	98	W10110491.....	24
DA47-00244D.....	66	DD31-00013B.....	34	L290.....	54	W10111389.....	105
DA47-00244Q.....	66	DD31-00016A.....	36	LA1008.....	51	W10116735.....	55
DA47-00244U.....	66	DD32-00005A.....	39	LA1044.....	45	W10120998.....	49
DA47-00244W.....	66	DD62-00043A.....	34	LA1053.....	53	W10124096.....	77
DA47-00285P.....	68	DB62-00067A.....	40	LA11AA005.....	56	W10128551.....	80

INDEX

W10131825.....	21	W10352689.....	65	W10836470.....	16	WB20K10023.....	31
W10136934.....	42	W10352973.....	91	W10837240.....	47	WB20K10026.....	31
W10141709.....	7	W10359269.....	52	W10846093.....	37	WB20K5027.....	31
W10144820.....	108	W10359272.....	52	W10853654.....	89	WB20K8.....	31
W10158389.....	40	W10370189.....	16	W10853723.....	109	WB20X5071.....	31
W10159016.....	31	W10380496.....	19	W10857622.....	13	WB21X5287.....	31
W10159839.....	88	W10383615.....	85	W10860916.....	24	WB23K10003.....	13
W10160375.....	16	W10384183.....	85	W10861225.....	42	WB23K5027.....	13
W10162384.....	19	W10391443.....	101	W10861521.....	20	WB23M24.....	13
W10162385.....	19	W10394076.....	89	W10865826.....	89	WB23X5340.....	22
W10165425.....	68	W10402110.....	39	W10869845.....	104	WB24T10022.....	13
W10167627.....	52	W10404050.....	96	W10876537.....	36	WB24T10025.....	13
W10169985.....	7	W10408179.....	89	W10876600.....	100	WB24T10027.....	13
W10175893.....	108	W10409079.....	100	W10879262.....	35	WB24T10029.....	13
W10179146.....	88	W10420083.....	89	W10881366.....	89	WB24T10058.....	13
W10181986.....	21	W10425238.....	101	W10888592.....	38	WB24T10063.....	13
W10183368.....	7	W10434452.....	13	W10906683.....	46	WB24T10071.....	25
W10185970.....	55	W10435302.....	92	W10909685.....	53	WB24T10119.....	14
W10185972.....	55	W10436303.....	55	W10913953.....	91	WB24T10134.....	14
W10185976.....	55	W10445975.....	35	W10919003.....	100	WB24T10146.....	14
W10185981.....	55	W10448874.....	84	W11043013.....	89	WB24T10153.....	14
W10185982.....	55	W10448876.....	105	W11050897.....	52	WB24T10162.....	14
W10185992.....	55	W10465252.....	100	W11084656.....	37	WB24X25013.....	14
W10186032.....	55	W10475147.....	24	W11088945.....	65	WB26K10038.....	63
W10188389.....	80	W10490648.....	18	W11096267.....	109	WB2X1522.....	20
W10189703.....	80	W10498976.....	89	W11117906.....	77	WB2X7909.....	2
W10192995.....	98	W10498990.....	89	W11122531.....	18	WB2X8228.....	29
W10195416.....	37	W10508950.....	32	W11122536.....	18	WB30K10002.....	26
W10197428.....	84	W10509257.....	34	W11122543.....	18	WB30K10003.....	26
W10199989.....	105	W10510667.....	36	W11122546.....	18	WB30T10044.....	28
W10207397.....	4	W10511278.....	24	W11122551.....	18	WB30T10045.....	28
W10209656.....	11	W10515459.....	11	W11122555.....	18	WB30T10047.....	28
W10209656KIT.....	11	W10516085.....	49	W11122557.....	19	WB30T10074.....	26
W10212596.....	108	W10524469.....	34	W11162730.....	24	WB30T10078.....	26
W10212598.....	108	W10528947.....	94	W11168740.....	109	WB30T10126.....	28
W10217917.....	88	W10536347.....	102	W11168743.....	109	WB30T10129.....	28
W10219643.....	40	W10537869.....	33	W11175771.....	40	WB30T10130.....	28
W10225581.....	68	W10546503.....	38	W11176265.....	48	WB30T10132.....	28
W10238100.....	88	W10547292.....	47	W11202789.....	77	WB30T10133.....	28
W10247306.....	109	W10556710.....	18	W11220230.....	109	WB30T10135.....	28
W10247710.....	104	W10581874.....	102	W11239857.....	92	WB30T10136.....	28
W10256908.....	20	W10583800.....	65	W11307244.....	96	WB30T10145.....	29
W10258275.....	39	W10599356.....	109	W11316246.....	99	WB30T10155.....	29
W10258562.....	88	W10605015.....	32	W11338583.....	76	WB30X24111.....	29
W10260319.....	92	W10613606.....	84	W11412291.....	37	WB30X31057.....	27
W10268911.....	99	W10619844.....	96	W11458345.....	102	WB30X31058.....	27
W10275048.....	28	W10619951.....	74	W11497943.....	37	WB31K10012.....	9
W10276397.....	101	W10636339.....	31	W11544663.....	16	WB31X20643.....	9
W10278150.....	11	W10658354.....	20	WB02X10700.....	9	WB32K3.....	20
W10279866.....	88	W10661045.....	100	WB03K10036.....	17	WB3X712.....	17
W10279909.....	88	W10683603.....	109	WB03K10159.....	17	WB44K10002.....	6
W10282492.....	20	W10698166.....	17	WB03K10187.....	17	WB44K10005.....	4
W10282960.....	19	W10717210.....	50	WB03K10202.....	17	WB44K5009.....	6
W10289387.....	109	W10721967.....	95	WB03K10216.....	16	WB44K5012.....	4
W10300924V.....	34	W10730972.....	102	WB03K10265.....	16	WB44K5013.....	4
W10312696.....	88	W10745655.....	55	WB03K10302.....	17	WB44T10009.....	6
W10314173.....	51	W10762263.....	17	WB03K10303.....	16	WB44T10010.....	4
W10316760.....	85	W10766544.....	16	WB03K10305.....	16	WB44T10011.....	4
W10321304.....	64	W10779716.....	4	WB03T10325.....	16	WB44T10014.....	4
W10324262.....	11	W10780045.....	105	WB03X23020.....	18	WB44T10104.....	5
W10326913.....	109	W10780048.....	105	WB06X10596.....	9	WB44X10009.....	5
W10327249.....	40	W10804664.....	98	WB08X10057.....	59	WB44X10016.....	5
W10328463.....	42	W10804665.....	98	WB13K10043.....	10	WB44X173.....	6
W10331686.....	24	W10820036.....	97	WB13T10076.....	24	WB44X200.....	5
W10333842.....	11	W10820039.....	94	WB16K10026.....	6	WB44X5043.....	5
W10339251.....	106	W10820048.....	105	WB17T10006.....	29	WB44X5082.....	5
W10339442.....	16	W10822278.....	69	WB17X5113.....	29	WB44X5099.....	5
W10341320.....	88	W10822553.....	104	WB19K10008.....	20	WB48T10011.....	20
W10341329.....	89	W10822580.....	80	WB19K10025.....	30	WB48T10063.....	21
W10348269.....	36	W10822681.....	89	WB19K31.....	23	WB48T10095.....	21
W10350564.....	64	W10828351.....	49	WB20K10010.....	31	WB48X5099.....	21

INDEX

WB6X486.....	9	WH01X0460.....	96	WM0612N.....	106	WR60X10141.....	80
WCOIL.....	56	WH01X10261.....	93	WR02X12208.....	64	WR60X10168.....	77
WD08X10016.....	34	WH01X10302.....	93	WR07X10131.....	82	WR60X10172.....	81
WD08X10057.....	34	WH01X10310.....	95	WR08X22874.....	83	WR60X10185.....	81
WD15X10003.....	40	WH01X10343.....	104	WR09X10042.....	65	WR60X10209.....	77
WD15X10011.....	40	WH01X10343KIT.....	104	WR09X10049.....	69	WR60X10220.....	77
WD21X10261.....	35	WH01X10727.....	104	WR09X10106.....	83	WR60X10257.....	81
WD8X227.....	34	WH01X20826.....	104	WR09X10107.....	83	WR60X10277.....	81
WD8X228.....	34	WH08X10024.....	93	WR13X10020.....	75	WR60X10307.....	81
WD8X229.....	34	WH08X10050.....	93	WR14X27230.....	73	WR60X10348.....	77
WDH6FT.....	95	WH10X10006.....	98	WR17X11705.....	76	WR60X162.....	80
WE01X10160.....	48	WH12X10334.....	97	WR24X10186.....	73	WR60X190.....	80
WE01X20374.....	48	WH12X10412.....	99	WR24X10228.....	73	WR60X203.....	80
WE03X10016.....	51	WH12X10476.....	99	WR24X10229.....	73	WR60X23584.....	81
WE03X23881.....	49	WH12X10479.....	99	WR24X10231.....	73	WR60X26085.....	81
WE09X20441.....	45	WH13X10024.....	109	WR24X10236.....	73	WR60X28783.....	81
WE12X10015.....	42	WH13X10025.....	109	WR24X445.....	73	WR60X29099.....	82
WE12X82.....	42	WH13X10026.....	110	WR24X446.....	73	WR60X30922.....	74
WE18X25100.....	49	WH13X10027.....	110	WR24X449.....	73	WR60X31522.....	81
WE18X26.....	50	WH13X10029.....	110	WR24X450.....	73	WR62X10055.....	76
WE1M1067.....	44	WH13X10037.....	110	WR2X9144.....	74	WR71X10077.....	70
WE1M333.....	44	WH13X10048.....	110	WR30X10093.....	76	WR71X2086.....	90
WE1M654.....	48	WH13X22314.....	110	WR50X10025.....	68	WR9X355.....	65
WE1X1263.....	48	WH13X22720.....	110	WR50X10068.....	68	WR9X480.....	69
WE25X205.....	43	WH13X25296.....	110	WR50X10108.....	68	WR9X483.....	69
WE3M26.....	43	WH13X26535.....	110	WR51X10038.....	67	WR9X489.....	69
WE49X20697.....	43	WH13X27314.....	110	WR51X10055.....	67	WR9X491.....	65
WE4M160.....	55	WH1X2727.....	93	WR51X442.....	67	WR9X502.....	69
WE4M415.....	43	WH1X2754.....	95	WR51X443.....	67	WR9X520.....	70
WE4M449.....	47	WH23X10028.....	102	WR55X10025.....	85	Y700854.....	17
WE4X444.....	47	WH23X10030.....	102	WR55X24064.....	64	ZC-02.....	58
WE4X739.....	47	WH23X26206.....	100	WR57X10033.....	89	ZS75.....	58
WE4X750.....	47	WH44X10288.....	98	WR57X10051.....	90		
WF271.....	86	WH49X10042.....	91	WR57X10086.....	90		
WFCB.....	86	WIM.....	76	WR60X10074.....	80		

